




DAEWOO
POWER PRODUCTS


DLM4300HP
LAWN MOWER



EXPLODED VIEW / DESPIECE / VUE ÉCLATÉE


www.daewoopowerproducts.com

Manufactured under license of Daewoo International Corporation, Korea
Fabricado bajo licencia de Daewoo International Corporation, Corea



PART NO.	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
1	DA04-GM0211-000008-01-001	BOLT M6X12	14
2	DA04-GM0211-000008-01-002	COVER COMP,CYLINDER HEAD	1
3	DA04-GM0211-000008-01-003	PACKING,HEADCOVER	1
4	DA04-GM0211-000008-01-004	ARM,ROCKER	2
5	DA04-GM0211-000008-01-005	PLATE,PUSH ROD GUIDE	1
6	DA04-GM0211-000008-01-006	SEAT, VALVE SPRING,IN	2
7	DA04-GM0211-000008-01-007	SPRING,VALVE	2
8	DA04-GM0211-000008-01-008	DIPSTICK	1
9	DA04-GM0211-000008-01-009	VALVE,IN	1
10	DA04-GM0211-000008-01-010	VALVE EXHAUST	1
11	DA04-GM0211-000008-01-011	SPARK PULG	1
12	DA04-GM0211-000008-01-012	BOLT M8X45	4
13	DA04-GM0211-000008-01-013	CYLINDER HEAD	1
14	DA04-GM0211-000008-01-014	GASKET,CYLINDER HEAD	1
15	DA04-GM0211-000008-01-015	PIN, DOWEL	2
16	DA04-GM0211-000008-01-016	ROD,PUSH	2
17	DA04-GM0211-000008-01-017	LIFTER,VALVE	2
18	DA04-GM0211-000008-01-018	SCRAPER RING SET ,PISTON	1
19	DA04-GM0211-000008-01-019	PISTON	1
20	DA04-GM0211-000008-01-020	PIN, PISTON	1
21	DA04-GM0211-000008-01-021	CLIP, PISTON	2
22	DA04-GM0211-000008-01-022	ROD ASSEMBLY., CONNECTING	1
23	DA04-GM0211-000008-01-023	CRANKCASE	1
24	DA04-GM0211-000008-01-024	BRAKE ASSEMBLY	1
25	DA04-GM0211-000008-01-025	BALL BEARING	1
26	DA04-GM0211-000008-01-026	OIL SEAL	1
27	DA04-GM0211-000008-01-027	FLAT WASHER	1
28	DA04-GM0211-000008-01-028	BREATHER VALVE	1
29	DA04-GM0211-000008-01-029	CROSSING SCREW	1
30	DA04-GM0211-000008-01-030	ADJUSTER ROCKER ARM	2
31	DA04-GM0211-000008-01-031	STAY,OIL TANK	1
32	DA04-GM0211-000008-01-032	FUEL TANK CAP COMP	1
33	DA04-GM0211-000008-01-033	BOLT STUD,RECOIL STARTER	2
34	DA04-GM0211-000008-01-034	IGNITION COIL ASSY	1
35	DA04-GM0211-000008-01-035	FLYWHEEL ASSEMBLY	1
36	DA04-GM0211-000008-01-036	IMPELLER	1
37	DA04-GM0211-000008-01-037	PULLEY,STARTER	1
38	DA04-GM0211-000008-01-038	NUT M12	1
39	DA04-GM0211-000008-01-039	COVER,FAN	1
40	DA04-GM0211-000008-01-040	HEXAGON BOLTS WITH FLANGE M6	6
41	DA04-GM0211-000008-01-041	STARTER COMP,RECOIL	1
42	DA04-GM0211-000008-01-042	FUEL TANK ASSEMBLY	1
43	DA04-GM0211-000008-01-043	BOLT STUD,RECOIL STARTER	1
44	DA04-GM0211-000008-01-044	FUEL LINE	1
45	DA04-GM0211-000008-01-045	CLIP,FUEL LINE	1
46	DA04-GM0211-000008-01-046	METAL CLAMP	1
47	DA04-GM0211-000008-01-047	SHAFT,GOVERNOR ARM	1
48	DA04-GM0211-000008-01-048	WASHER,GOVERNOR ARM SHAFT	1
49	DA04-GM0211-000008-01-049	SEAL,GOVERNOR ARM SHAFT	1

50	DA04-GM0211-000008-01-050	PIN, LOCK	1
51	DA04-GM0211-000008-01-051	GOVERNOR ARM	1
52	DA04-GM0211-000008-01-052	BOLT, GOVERNOR ARM	1
53	DA04-GM0211-000008-01-053	SHROUD ASSY, UPPER	1
54	DA04-GM0211-000008-01-054	TUBE, BREATHER	1
55	DA04-GM0211-000008-01-055	SPRING, GOVERNOR	1
56	DA04-GM0211-000008-01-056	ROD, GOVERNOR	1
57	DA04-GM0211-000008-01-057	SPRING, THROTTLE RETURN	1
58	DA04-GM0211-000008-01-058	BOLT, STUD	4
59	DA04-GM0211-000008-01-059	GASKET, AIR CLEANER	2
60	DA04-GM0211-000008-01-060	INSULATOR, CARBURETOR	1
61	DA04-GM0211-000008-01-061	GASKET, CARBURETOR	1
62	DA04-GM0211-000008-01-062	CARBURETOR ASSEMBLY	1
63	DA04-GM0211-000008-01-063	AIR CLEANER ASSEMBLY	1
64	DA04-GM0211-000008-01-064	PACKING, EXHAUST	1
65	DA04-GM0211-000008-01-065	MUFFLER COMP	1
66	DA04-GM0211-000008-01-066	SHIELD, OUT MUFFLER	1
67	DA04-GM0211-000008-01-067	OIL SEAL	1
68	DA04-GM0211-000008-01-068	COVER ASSEMBLY, CRANKCASE	1
69	DA04-GM0211-000008-01-069	SHROUD	1
70	DA04-GM0211-000008-01-070	CRANKSHAFT ASSY	1
71	DA04-GM0211-000008-01-071	CAMSHAFT ASSEMBLY	1
72	DA04-GM0211-000008-01-072	PACKING, CASECOVER	1
73	DA04-GM0211-000008-01-073	DOWEL PIN, CASECOVER	2
74	DA04-GM0211-000008-01-074	GOVERNOR ASSEMBLY	1
75	DA04-GM0211-000008-01-075	WASHER, DRAIN PLUG	1
76	DA04-GM0211-000008-01-076	BOLT, DRAIN PLUG	1
77	DA04-GM0211-000008-01-077	GASKET, BREATHER CHAMBER	1
78	DA04-GM0211-000008-01-078	CAP, BREATHER CHAMBER	1
79	DA04-GM0211-000008-01-079	NUT M6	2
80	DA04-GM0211-000008-01-080	BOLT M6X35	7
81	DA04-GM0211-000008-01-081	BOLT M6X16	3
82	DA04-GM0211-000008-01-082	BOLT M6X20	2



PART NO.	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
1	DA04-GM0211-000008-02-083	BOLT BS1768 3/8-24UNF*38	1
2	DA04-GM0211-000008-02-084	FLAT WASHER	1
3	DA04-GM0211-000008-02-085	BLADE WASHER	1
4	DA04-GM0211-000008-02-086	BLADE	1
5	DA04-GM0211-000008-02-087	BLADE ADAPTER	1
6	DA04-GM0211-000008-02-088	BUSH (BLADE ADAPTER)	1
7	DA04-GM0211-000008-02-089	KEY	1
8	DA04-GM0211-000008-02-090	DECK	1
9	DA04-GM0211-000008-02-091	NUT GB6183 M6	8
10	DA04-GM0211-000008-02-092	FRONT AXLE PLANK	2
11	DA04-GM0211-000008-02-093	BOLT GB5787 M6*14	8
12	DA04-GM0211-000008-02-094	BOLT GB5783 M8*30	3
13	DA04-GM0211-000008-02-095	SPRING WASHER GB93	3
14	DA04-GM0211-000008-02-096	WASHER GB96	3
15	DA04-GM0211-000008-02-097	ENGINE	1
16	DA04-GM0211-000008-02-098	REAR AXLE PLANK	2
17	DA04-GM0211-000008-02-099	NUT GB6183 M8	4
18	DA04-GM0211-000008-02-100	BOLT M8*45	4
19	DA04-GM0211-000008-02-101	STEM	2
20	DA04-GM0211-000008-02-102	CIRCLIP Ø5	2
21	DA04-GM0211-000008-02-103	TORSIONAL SPRING (L)	1
22	DA04-GM0211-000008-02-104	AXLE(REAR COVER)	1
23	DA04-GM0211-000008-02-105	REAR COVER	1
24	DA04-GM0211-000008-02-106	TORSIONAL SPRING (R)	1
25	DA04-GM0211-000008-02-107	BOLT GB5783 M8*16	4
26	DA04-GM0211-000008-02-108	RIGHT HANDLE SUPPORT	1
27	DA04-GM0211-000008-02-109	KNOB (SMALL)	2
28	DA04-GM0211-000008-02-110	LOWER HANDLE	1
29	DA04-GM0211-000008-02-111	CLIP	1
30	DA04-GM0211-000008-02-112	BRAKE LEVEL	1
31	DA04-GM0211-000008-02-113	SOFT GRIP	1
32	DA04-GM0211-000008-02-114	NUT M6	2
33	DA04-GM0211-000008-02-115	BRAKE CABLE	1
34	DA04-GM0211-000008-02-116	BOLT M6*35	1
35	DA04-GM0211-000008-02-117	UPPER HANDLE	1
36	DA04-GM0211-000008-02-118	ROPE GUIDE SUPPORT	1
37	DA04-GM0211-000008-02-119	NUT GB6177 M6	1
38	DA04-GM0211-000008-02-120	KNOB(BIG)	2
39	DA04-GM0211-000008-02-121	RIGHT HANDLE SUPPORT	1

40	DA04-GM0211-000008-02-122	FRAME	1
41	DA04-GM0211-000008-02-123	GRASS BAG	1
42	DA04-GM0211-000008-02-124	FRONT WHEEL OUTER COVER	4
43	DA04-GM0211-000008-02-125	NUT M10	4
44	DA04-GM0211-000008-02-126	BOLT	2
45	DA04-GM0211-000008-02-127	HEIGHT ADJUSTER COVER	1
46	DA04-GM0211-000008-02-128	HEIGHT ADJUSTER LEVER	1
47	DA04-GM0211-000008-02-129	SPRING LAMINATION(HEIGHT ADJUSTER)	1
48	DA04-GM0211-000008-02-130	BOLT GB5783 M6*14	4
49	DA04-GM0211-000008-02-131	REAR AXLE	1
50	DA04-GM0211-000008-02-132	NUT GB6182 M6	6
51	DA04-GM0211-000008-02-133	HEIGHT ADJUSTMENT LINK BAR	1
52	DA04-GM0211-000008-02-134	HEIGH ADJUSTER SPING	1
53	DA04-GM0211-000008-02-135	FRONT WHEEL	2
54	DA04-GM0211-000008-02-136	FLAT WASHER	4
55	DA04-GM0211-000008-02-137	WASHER GB97	2
56	DA04-GM0211-000008-02-138	HOLD HOOP	2
57	DA04-GM0211-000008-02-139	FRONT AXLE	1
58	DA04-GM0211-000008-02-140	REAR WHEEL OUTER COVER	2
59	DA04-GM0211-000008-02-141	FRONT WHEEL INNER COVER	2
60	DA04-GM0211-000008-02-142	REAR WHEEL INNER COVER	2
61	DA04-GM0211-000008-02-143	REAR WHEEL	2