



DAEWOO

POWER PRODUCTS

DALHT62-24


CORDLESS HEDGE TRIMMER



EXPLODED VIEW

www.daewoopowerproducts.com

Manufactured under license of Daewoo International Corporation, Korea
Fabricado bajo licencia de Daewoo International Corporation, Corea



PART NO.	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
1	DA04-HT0211-000034-00-001	PROTECTIVE COVER	1
2	DA04-HT0211-000034-00-002	SELF-DRIVING SCREW	27
3	DA04-HT0211-000034-00-003	AUXILIARY HANDLE GRIP	1
4	DA04-HT0211-000034-00-004	HEXAGON SOCKET BOLT	10
5	DA04-HT0211-000034-00-005	SWITCH TRIGGER SPRING	4
6	DA04-HT0211-000034-00-006	AUXILIARY HANDLE GRIP TRIGGER	1
7	DA04-HT0211-000034-00-007	WASHER	2
8	DA04-HT0211-000034-00-008	LEFT PRESSING PLATE	1
9	DA04-HT0211-000034-00-009	RIGHT PRESSING PLATE	1
10	DA04-HT0211-000034-00-010	SELF-DRIVING SCREW	2
11	DA04-HT0211-000034-00-011	SWITCH PRESSING PLATE	1
12	DA04-HT0211-000034-00-012	MICRO SWITCH	2
13	DA04-HT0211-000034-00-013	ANCILLARY HANDLE GRIP WIRING HARNESS	1
14	DA04-HT0211-000034-00-014	BLADE SHEATH	1
15	DA04-HT0211-000034-00-015	BLADE ASS'Y	1
16	DA04-HT0211-000034-00-016	WOOL FELT	1
17	DA04-HT0211-000034-00-017	BLADE BUSHING	2
18	DA04-HT0211-000034-00-018	BLADE GASKET	2
19	DA04-HT0211-000034-00-019	SPRING WASHER	4
20	DA04-HT0211-000034-00-020	HEXAGON SCREW	2
21	DA04-HT0211-000034-00-021	SPRING WASHER	4
22	DA04-HT0211-000034-00-022	GEAR BOX COVER	1
23	DA04-HT0211-000034-00-023	CONNECTING ROD LIMIT PLATE	2
24	DA04-HT0211-000034-00-024	BEARING	1
25	DA04-HT0211-000034-00-025	HEXAGON SCREW	4
26	DA04-HT0211-000034-00-026	BEARING	1
27	DA04-HT0211-000034-00-027	AXLE SLEEVE	1
28	DA04-HT0211-000034-00-028	CONNECTING ROD	2
29	DA04-HT0211-000034-00-029	BIG GEAR	1
30	DA04-HT0211-000034-00-030	GASKET	1
31	DA04-HT0211-000034-00-031	TRANSMISSION SHAFT	1
32	DA04-HT0211-000034-00-032	BEARING	1
33	DA04-HT0211-000034-00-033	HEXAGON SCREW	2
34	DA04-HT0211-000034-00-034	GEAR BOX	1
35	DA04-HT0211-000034-00-035	BRUSHLESS MOTOR	1
36	DA04-HT0211-000034-00-036	CONTROLLER	1
37	DA04-HT0211-000034-00-037	LEFT SHELL	1
38	DA04-HT0211-000034-00-038	LEFT AIR WINDOW	1
39	DA04-HT0211-000034-00-039	RIGHT AIR WINDOW	1
40	DA04-HT0211-000034-00-040	RIGHT SHELL	1
41	DA04-HT0211-000034-00-041	RIGHT HANDLE GRIP	1
42	DA04-HT0211-000034-00-042	SWITCH TRIGGER	1
43	DA04-HT0211-000034-00-043	MALE BATTERY TERMINAL	3
44	DA04-HT0211-000034-00-044	ROTATING PULLING BUTTON SPRING	1
45	DA04-HT0211-000034-00-045	ROTATING PULLING BUTTON	1
46	DA04-HT0211-000034-00-046	PUSH BLOCK	1
47	DA04-HT0211-000034-00-047	PUSH SPRING	2
48	DA04-HT0211-000034-00-048	PUSH BLOCK BASE	1
49	DA04-HT0211-000034-00-049	PUSH SWITCH	1
50	DA04-HT0211-000034-00-050	PUSH BUTTON	1
51	DA04-HT0211-000034-00-051	BATTERY PACK MALE SOCKET	1
52	DA04-HT0211-000034-00-052	SELF-LOCKING BUTTON	1
53	DA04-HT0211-000034-00-053	COLUMN PIN	1
54	DA04-HT0211-000034-00-054	LOCKING BUTTON	1
55	DA04-HT0211-000034-00-055	LOCKING BUTTON	1
56	DA04-HT0211-000034-00-056	LOWER HANDLE SPRING	1
57	DA04-HT0211-000034-00-057	LEFT HANDLE GRIP	1
58	DA04-HT0211-000034-00-058	SELF-DRIVING SCREW	4
59	DA04-HT0211-000034-00-059	MAGNETIC SNAP	1