




DAEWOO
POWER PRODUCTS

GAET50


GASOLINE WATER PUMP




EXPLODED VIEW / DESPIECE / VUE ÉCLATÉE

www.daewoopowerproducts.com

Manufactured under license of Daewoo International Corporation, Korea
Fabricado bajo licencia de Daewoo International Corporation, Corea





PART NO.	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
1	DA01-GP1111-000009-00-001	CLIP TUBE	2
2	DA01-GP1111-000009-00-002	TUBE FUEL	1
3	DA01-GP1111-000009-00-003	JOINT ASSY FUEL TANK	1
4	DA01-GP1111-000009-00-004	CAP COMP FUEL FILLER	1
5	DA01-GP1111-000009-00-005	FILTER FUEL	1
6	DA01-GP1111-000009-00-006	TANK COMP FUEL	1
7	DA01-GP1111-000009-00-007	SPRING THROTTLE RETURN	1
8	DA01-GP1111-000009-00-008	SPRING THROTTLE RETURN	1
9	DA01-GP1111-000009-00-009	ARM GOVERNOR	1
10	DA01-GP1111-000009-00-010	NUT FLANGE	3
11	DA01-GP1111-000009-00-011	PIN LOCK	1
12	DA01-GP1111-000009-00-012	SHAFT GOVERNOR ARM	1
13	DA01-GP1111-000009-00-013	ROD GOVERNOR	1
14	DA01-GP1111-000009-00-014	BOLT FLANGE	6
15	DA01-GP1111-000009-00-015	BOLT QUADRATE HEAD	1
16	DA01-GP1111-000009-00-016	CONTROL ASSY	1
17	DA01-GP1111-000009-00-017	WASHER PAIN	2
18	DA01-GP1111-000009-00-018	KNOB RECOIL STARTER	1
19	DA01-GP1111-000009-00-019	COVER COMP FAN	1
20	DA01-GP1111-000009-00-020	SPRING RECOIL SATRTER	1
21	DA01-GP1111-000009-00-021	REEL RECOIL STARTER	1
22	DA01-GP1111-000009-00-022	ROPE	1
23	DA01-GP1111-000009-00-023	SPRING RETURN	2
24	DA01-GP1111-000009-00-024	RATCHET STARTER	2
25	DA01-GP1111-000009-00-025	GUIDE RATCHET	1
26	DA01-GP1111-000009-00-026	SCREW SETTING	1
27	DA01-GP1111-000009-00-027	SWITCH ASSY ENGINE STOP(OIL ALERT)	1
28	DA01-GP1111-000009-00-028	COVER COMP FAN	1
29	DA01-GP1111-000009-00-029	NUT SPECIAL	1
30	DA01-GP1111-000009-00-030	PULLEY STARTER	1
31	DA01-GP1111-000009-00-031	FAN COOLING	1
32	DA01-GP1111-000009-00-032	FLYWHEEL COMP	1
33	DA01-GP1111-000009-00-033	DIVERSION ASSY	1
34	DA01-GP1111-000009-00-034	OIL SEAL25*41.25*6	2
35	DA01-GP1111-000009-00-035	PLATE SIDE SUPPORT	1
36	DA01-GP1111-000009-00-036	ALART UNIT OIL	1
37	DA01-GP1111-000009-00-037	BOLT DRAIN PLUG	2
38	DA01-GP1111-000009-00-038	WASHER DRAIN PLUG	2
39	DA01-GP1111-000009-00-039	CRANKCASE	1
40	DA01-GP1111-000009-00-040	BEARING RADIAL BALL	2
41	DA01-GP1111-000009-00-041	OIL LEVEL SWITCH	1
42	DA01-GP1111-000009-00-042	GEAR GOVERNOR	1
43	DA01-GP1111-000009-00-043	PIN GOVERNOR WEIGHT	2
44	DA01-GP1111-000009-00-044	SHAFT GOVERNOR	1
45	DA01-GP1111-000009-00-045	CLIP GOVERNOR HOLDER	1
46	DA01-GP1111-000009-00-046	WEIGHT GOVERNOR	2
47	DA01-GP1111-000009-00-047	WASHER PAIN	1
48	DA01-GP1111-000009-00-048	SLIDER GOVERNOR	1
49	DA01-GP1111-000009-00-049	CRANKSHAFT COMP	1
50	DA01-GP1111-000009-00-050	PACKING CASE COVER	1
51	DA01-GP1111-000009-00-051	OIL FILLER CAP	1
52	DA01-GP1111-000009-00-052	PACKING OIL FILLER CAP	2
53	DA01-GP1111-000009-00-053	COVER	1
54	DA01-GP1111-000009-00-054	BOLT FLANGE	6
55	DA01-GP1111-000009-00-055	BOLT FLANGE	3
56	DA01-GP1111-000009-00-056	NUT TOOL BOX SETTING	1
57	DA01-GP1111-000009-00-057	COVER AIR CLEANER	1
58	DA01-GP1111-000009-00-058	SEAL AIR CLEANER	1
59	DA01-GP1111-000009-00-059	COVER AIR CLEANER	1
60	DA01-GP1111-000009-00-060	FILTER OUTER	1
61	DA01-GP1111-000009-00-061	NOSE SILENCER	1
62	DA01-GP1111-000009-00-062	ELBOW COMP AIR CLEANER	1
63	DA01-GP1111-000009-00-063	BOLT FLANGE 6*30	2
64	DA01-GP1111-000009-00-064	COIL ASSY IGNITION	1
65	DA01-GP1111-000009-00-065	PIN DOWER	2
66	DA01-GP1111-000009-00-066	BOLT FLANGE 8*55	4
67	DA01-GP1111-000009-00-067	SPACER COMP AIR CLEANER	1
68	DA01-GP1111-000009-00-068	LEVER COMP CHOKE	1

PART NO.	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
69	DA01-GP1111-000009-00-069	CARBURETOR	1
70	DA01-GP1111-000009-00-070	PACKING CABURETOR	1
71	DA01-GP1111-000009-00-071	INSULATOR CARBURETOR	1
72	DA01-GP1111-000009-00-072	PACKING INSUL ATOR	1
73	DA01-GP1111-000009-00-073	BOLT STUD IN	2
74	DA01-GP1111-000009-00-074	TUBE BREATHER	1
75	DA01-GP1111-000009-00-075	COVER COMP HEAD	1
76	DA01-GP1111-000009-00-076	PACKING HEAD COVER	1
77	DA01-GP1111-000009-00-077	RATATOR VALVE	2
78	DA01-GP1111-000009-00-078	SEAL GUIDE	1
79	DA01-GP1111-000009-00-079	RETAINER VALVE SPRING	2
80	DA01-GP1111-000009-00-080	SPRING VALVE	2
81	DA01-GP1111-000009-00-081	PLUG SPARK	1
82	DA01-GP1111-000009-00-082	HEAD COMP CYLINDER	1
83	DA01-GP1111-000009-00-083	GASKET CYLINDER	1
84	DA01-GP1111-000009-00-084	VALVE IN	1
85	DA01-GP1111-000009-00-085	VALVE EX	1
86	DA01-GP1111-000009-00-086	LEFTER VALVE	2
87	DA01-GP1111-000009-00-087	CAMSHAFT ASSY	1
88	DA01-GP1111-000009-00-088	PIN FLYING BLOCK	1
89	DA01-GP1111-000009-00-089	NUT PIVOT ADJUSTING	2
90	DA01-GP1111-000009-00-090	PIVOT ROCKER ARM	2
91	DA01-GP1111-000009-00-091	ARM VALVE ROCKER	2
92	DA01-GP1111-000009-00-092	BOLT PIVOT ARM	2
93	DA01-GP1111-000009-00-093	PLATE ASSY	1
94	DA01-GP1111-000009-00-094	ROD PUSH	2
95	DA01-GP1111-000009-00-095	KEY SPECIAL WOODRUFF	1
96	DA01-GP1111-000009-00-096	SCREW TAPPINIG 5*8	4
97	DA01-GP1111-000009-00-097	PROTECTOR MUFFLER	1
98	DA01-GP1111-000009-00-098	MUFFLER ASSY	1
99	DA01-GP1111-000009-00-099	NUT HEX 8MM	1
100	DA01-GP1111-000009-00-100	GASKET MUFFLER	1
101	DA01-GP1111-000009-00-101	BOLT STUD EXHAUST	1
102	DA01-GP1111-000009-00-102	SHROUD	1
103	DA01-GP1111-000009-00-103	RING SET	1
104	DA01-GP1111-000009-00-104	PISTON	1
105	DA01-GP1111-000009-00-105	CLIP PISTON PIN	2
106	DA01-GP1111-000009-00-106	PIN PISTON	1
107	DA01-GP1111-000009-00-107	CONNECTING ROD	1
108	DA01-GP1111-000009-00-108	OIL STICK	1
109	DA01-GP1111-000009-00-109	PUMP COVER	1
110	DA01-GP1111-000009-00-110	O RING(COVER)	1
111	DA01-GP1111-000009-00-111	GASKETφ8	4
112	DA01-GP1111-000009-00-112	BLOT M8*60	4
113	DA01-GP1111-000009-00-113	MECHANICAL SEAL	1
114	DA01-GP1111-000009-00-114	IMPELLER	1
115	DA01-GP1111-000009-00-115	VOLUTE	1
116	DA01-GP1111-000009-00-116	O RING (VOLUTE)	1
117	DA01-GP1111-000009-00-117	PUMP BODY	1
118	DA01-GP1111-000009-00-118	GASKET (OUTLET)	1
119	DA01-GP1111-000009-00-119	IRON GASKET	4
120	DA01-GP1111-000009-00-120	BLOT	4
121	DA01-GP1111-000009-00-121	O RING (PRIMING CAP)	2
122	DA01-GP1111-000009-00-122	PRIMING CAP	2
123	DA01-GP1111-000009-00-123	SPANNER	2
124	DA01-GP1111-000009-00-124	COULPING	2
125	DA01-GP1111-000009-00-125	GASKET (COULPING)	2
126	DA01-GP1111-000009-00-126	INLET	1
127	DA01-GP1111-000009-00-127	CHECK	1
128	DA01-GP1111-000009-00-128	OUTLET	1
129	DA01-GP1111-000009-00-129	BOLOT	3
130	DA01-GP1111-000009-00-130	CLIP	3
131	DA01-GP1111-000009-00-131	FLITER	1
132	DA01-GP1111-000009-00-132	FRAME	1
133	DA01-GP1111-000009-00-133	RUBBER SHOCKER	4
134	DA01-GP1111-000009-00-134	SCREW M8	8
135	DA01-GP1111-000009-00-135	BLOT M8*32	4