



PS-20 Knapsack power sprayer (1)



No	Code	Name	Qty	No	Code	Name	Qty
1		LID	1	26		PLASTIC NUT	2
2	032565	LID	1	27	013390	RUBBER MOUNT	2
3	032566	SEALING WASHER	1	28		CONNECT PLATE	1
4	032567	FILTER ASSM	1	29		SCREW ASSEM 5x20	2
5		FILTER ASSM	1	30	13391	SUPPORT MOUNT	1
6	032568	CHEMICAL TANK	1	31		RIGHT SUPPORT	1
7		CLICK	2	32		LEFT SUPPORT	1
8	032559	BANDS ASSM	2	33	013392	LONG NOZZLE	1
9	013384	SEALING WASHER	1	34	013393	STAIGHT SPRAYING TUBE	1
10		LID	1	35	032560	SEAL RING	4
11		SCREW	4	36	013394	VALVE	1
12		WASHER 6	9	37	013396	HANDLE	1
13		FRAME	1	38	13395	RUBBER TUBE ASSY	1
14		PLASTIC CLICK	4	39		O-RING 10x2.65	1
15	013386	BACK DACK ASSM	1	40	13390	RUBBER MOUNT	1
16		NUT M8	1	41			
17		WASHER 8	1	42			
18	013387	CONTROL SEAT	1	43			
19	16262	STOP SWITCH ASSY	1	44			
20	013388	SWITH	1	45			
21		NUT M6	6	46			
22		SCREW ASSY M5 x12	1	47			
23		BOLT M6 x 20	3	48			
24	013389	FREL THROTTLE	1	49			
25		GROUND WIRE	1	50			


PS-20 Knapsack power sprayer (2)



No	Code	Name	Qty	No	Code	Name	Qty
8		SCREW	1	69		SCREW	1
11		WASHER	1	70		SEAL	1
25		TUBE	1	71		O-RING	1
47		BOX	1	72		RING	1
48		PISTON	1	73		SEAL	1
50		GEAR SHAFT	1	74		RING	1
51		BEARING	1	75		SEAL	1
52		O-RING	1	76		SEAL	1
53		WASHER	1	77		SEAT	1
54		WASHER	1	78		CYLINDER	1
55		LID	1	79+80		RING	1
56		CLUTCH DRUM COVER	1	81		PISTON	1
57		BEARING	1	82	036775	DISCHARGE METAL	1
58		BEARING	1	83		CLIP	1
60		GEAR	1	85		OVERFLOW METAL	1
61		BEARING	1	86		VALVE SEAT	1
62		O-RING	1	88		BALL	1
63		LID	1	89		CONE	1
64-1		O-RING	1	90		SPRING	1
65		SCREW	1	92		SCREW	1
66		O-RING	1	93	036778	VALVE	1
67		RULE	1	94		NUT	1
68		O-RING	1	95		SHAFT	1

[illegible]

PS-20 Engine



No	Code	Name	Qty	No	Code	Name	Qty
1	013449	SCREW	1	24		STOP CORD COMP.	1
2	013450	CLEANER OUTSIDE COVER	1	25		PRIMARY CORD GROMMET	1
3	10888	CLEANER ELEMENT	1	26	19863	MAGNETO STATOR	1
4		SCREW M5X55	2	26A	13460	MAGNETO ROTOR	1
5	013452	CLEANER INSIDE COVER	1	27		SCREW M5X25	4
6		SCREW ST4.2X12-F-H	1	28	032563	FRONT HALF CRANK CASE	1
7	14028	CHOKE	1	29	016279	GUIDE PLATE	1
8		CHOKE HANDLE	1	30	016291	CRANK CASE GASKET	1
9	10887	CARBURETOR	1	31	10860	OIL SEAL	2
10	013454	GASKET	1	32	21113	BALL BEARING 6001/P5	2
11		SCREW M5X20	6	33		KEY	1
12	013455	INLET MANIFOLD	1	34	013462	CRANK SHAFT COMP.	1
13	013456	CYLINDER WASHER	1	35	032564	REAR HALF CRANK CASE	1
14		ANNUL B3X10	4	36		STARTER PULLEY ASS'Y	1
15		SCREW M4X16	9	37	16294	STARTER PAWL SPRING	1
16		FAN COVER	1	38		STARTER PAWL	1
17	028403	CLUTCH STEP SCREW	2	39	036783	SCREW M5X10	1
18	028402	WASHER	2	40	016302	RECOIL SPRING	1
19	013457	CLUTCH SHOE COMP.	2	41	016305	STARTER ROPE REEL	1
20		WASHER	2	42		RECOIL STARTER BODY	1
21	013458	CLUTCH SPRING	1	43		ROPE GUIDE	1
22		NUT M8X1	1	44	016303	ROPE	1
23		WASHER 8	1	45	016304	STARTER HANDLE	1

