




DAEWOO
POWER PRODUCTS

DCS2416E


Electric Chainsaw



EXPLODED VIEW / DESPIECE / VUE ÉCLATÉE

www.daewoopowerproducts.com

Manufactured under license of Daewoo International Corporation, Korea
Fabricado bajo licencia de Daewoo International Corporation, Corea



PART NO.	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
1	DA04-CS1811-000128-00-001	Power Cord	1
2	DA04-CS1811-000128-00-002	Press Board	1
3	DA04-CS1811-000128-00-003	Self-Tape Screw	15
4	DA04-CS1811-000128-00-004	Cable Sheath	1
5	DA04-CS1811-000128-00-005	Lock Off Button	1
6	DA04-CS1811-000128-00-006	Lock Off Switch Spring	1
7	DA04-CS1811-000128-00-007	Switch Trigger	1
8	DA04-CS1811-000128-00-008	Self-Tape Screw	1
9	DA04-CS1811-000128-00-009	Self-Tape Screw	21
10	DA04-CS1811-000128-00-010	Motor Rear Cover	1
11	DA04-CS1811-000128-00-011	Protective Guard	1
12	DA04-CS1811-000128-00-012	Flat Washer	1
13	DA04-CS1811-000128-00-013	Self-Tape Screw	1
14	DA04-CS1811-000128-00-014	Left Housing	1
15	DA04-CS1811-000128-00-015	Spring gasket	1
16	DA04-CS1811-000128-00-016	Flange head Self-Tape Screw	1
17	DA04-CS1811-000128-00-017	Protective Guard Gasket	1
18	DA04-CS1811-000128-00-018	Carbon Brush	2
19	DA04-CS1811-000128-00-019	Brush Holder	2
20	DA04-CS1811-000128-00-020	Rear Bracket for motor	1
21	DA04-CS1811-000128-00-021	Hex Nut	2
22	DA04-CS1811-000128-00-022	Flange head Self-Tape Screw	4
23	DA04-CS1811-000128-00-023	Stator	1
24	DA04-CS1811-000128-00-024	Wind Shield Board	1
25	DA04-CS1811-000128-00-025	Flat washer	2
26	DA04-CS1811-000128-00-026	Spring Washer	2
27	DA04-CS1811-000128-00-027	Stator Screw	2
28	DA04-CS1811-000128-00-028	Deep Groove Ball Bearing	1
29	DA04-CS1811-000128-00-029	Rotor	1
30	DA04-CS1811-000128-00-030	Deep Groove Ball Bearing	1
31	DA04-CS1811-000128-00-031	Middle Support Board	1
32	DA04-CS1811-000128-00-032	Motor Gear Spindle Sleeve	1
33	DA04-CS1811-000128-00-033	Pinion	1
34	DA04-CS1811-000128-00-034	Flange Head Nut	2
35	DA04-CS1811-000128-00-035	Oil Outlet Tip	1
36	DA04-CS1811-000128-00-036	O Sealing Ring	1
37	DA04-CS1811-000128-00-037	Capacitor	1
38	DA04-CS1811-000128-00-038	Switch	2
39	DA04-CS1811-000128-00-039	Push Rod	1
40	DA04-CS1811-000128-00-040	Push Rod Spring	1
41	DA04-CS1811-000128-00-041	Gear Assembly	1
41-1	DA04-CS1811-000128-00-042	Lock Nut	1
41-2	DA04-CS1811-000128-00-043	Deep Groove Ball Bearing	1
41-3	DA04-CS1811-000128-00-044	Big Gear	1
41-4	DA04-CS1811-000128-00-045	Spindle Sleeve	1
41-5	DA04-CS1811-000128-00-046	Torsion Spring	1
41-6	DA04-CS1811-000128-00-047	Output Shaft	1
41-7	DA04-CS1811-000128-00-048	Deep Groove Ball Bearing	1

42	DA04-CS1811-000128-00-049	Dust-Proof Cover	1
43	DA04-CS1811-000128-00-050	Brake System Assembly	0
43-1	DA04-CS1811-000128-00-051	Flat Washer	1
43-2	DA04-CS1811-000128-00-052	Brake Rod Spring	1
43-3	DA04-CS1811-000128-00-053	Brake Rod	1
43-4	DA04-CS1811-000128-00-054	Connecting Rod	1
43-5	DA04-CS1811-000128-00-055	Brake Rod Fixing Board	1
44	DA04-CS1811-000128-00-056	Oil Inlet Pipe	1
45	DA04-CS1811-000128-00-057	Oil Pump Assembly	1
46	DA04-CS1811-000128-00-058	Oil Outlet Pipe	1
47	DA04-CS1811-000128-00-059	Oil Tank Assembly	1
47-1	DA04-CS1811-000128-00-060	Oil Tank Sealing Ring	1
47-2	DA04-CS1811-000128-00-061	Oil Tank Connecting Tip	1
47-3	DA04-CS1811-000128-00-062	Foam Boss	1
47-4	DA04-CS1811-000128-00-063	Oil Tank Connecting Tip Cap	1
47-5	DA04-CS1811-000128-00-064	Oil Tank	1
47-6	DA04-CS1811-000128-00-065	Valve	1
47-7	DA04-CS1811-000128-00-066	Oil Tank Cap Sealing Ring	1
47-8	DA04-CS1811-000128-00-067	Oil Tank Cap	1
47-9	DA04-CS1811-000128-00-068	Cap Retaining Hook	1
48	DA04-CS1811-000128-00-069	Right Housing	1
49	DA04-CS1811-000128-00-070	Tension Spring	1
50	DA04-CS1811-000128-00-071	Sprocket	1
51	DA04-CS1811-000128-00-072	E shape Circlip	1
52	DA04-CS1811-000128-00-073	Sealing Ring	1
53	DA04-CS1811-000128-00-074	Buffer Board	1
54	DA04-CS1811-000128-00-075	Sunk Self-Taping Screw	2
55	DA04-CS1811-000128-00-076	Connecting Wire1	1
56	DA04-CS1811-000128-00-077	Connecting Wire2	1
57	DA04-CS1811-000128-00-078	Connecting Wire3	1
58	DA04-CS1811-000128-00-079	Screw to fix the Chain Bar	1
59	DA04-CS1811-000128-00-080	Chain Bar	1
60	DA04-CS1811-000128-00-081	Bush	1
61	DA04-CS1811-000128-00-082	Push Plate	1
62	DA04-CS1811-000128-00-083	Spiral Wheel	1
63	DA04-CS1811-000128-00-084	Gasket	1
64	DA04-CS1811-000128-00-085	Circlip	1
65	DA04-CS1811-000128-00-086	Chain	1
66	DA04-CS1811-000128-00-087	Bar sleeve	1
67	DA04-CS1811-000128-00-088	Chain Wheel Cover	1
68	DA04-CS1811-000128-00-089	Circlip	1
69	DA04-CS1811-000128-00-090	Adjustig Ring	1
70	DA04-CS1811-000128-00-091	Tighten Knob	1