


VT 848



FRAME



EXPLODED PARTS LIST

Year: 2022.


Page(s): 2/32

VT 848

[illegible]

FRAME

VT 848



REAR PLATE



EXPLODED PARTS LIST

Year: 2022.


Page(s): 4/32

VT 848

[illegible]

REAR PLATE

VT 848



BODY WORK



EXPLODED PARTS LIST


Year: 2022.
Page(s): 6/32

VT 848

No	Code	Name	Qty	No	Code	Name	Qty
1		Air Conveyor	1	60		Cover	1
2		Screw	6	61		Cover	1
3		Screw	12	62		Screw	4
4		Engine Hood Support	1	63		Cover	1
5		Screw	4				
6		Air Intake Grill	1				
6		Air Intake Grill	1				
7		Air Intake Grill	1				
7		Air Intake Grill	1				
8	071996	Engine Hood Yellow	1				
8		Engine Hood Black	1				
8		Engine Hood Red	1				
8		Engine Hood Orange	1				
9		Air Conveyor	1				
9		Air Conveyor	1				
11		Dashboard Support	1				
12		Screw	4				
13		Guide	2				
14		Screw	6				
15		Screw	3				
16		Washer	3				
17	77329	Dashboard	1				
18		Screw	2				
19		Grommet	2				
21		Dashboard Cover	1				
22	71997	Frontal Bonnet	1				
23		Right Headlight Transparent	1				
24		Left Headlight Transparent	1				
25		Cover, Red	1				
25		Cover, Red	1				
25	49960	Cover, Yellow	1				
25		Black Central Cover	1				
25		Orange Central Cover	1				
26		Screw	1				
27		Right Lamp Support	1				
28		Left Lamp Support	1				
29		Light Reflected Label	1				
34		Red Wheels Cover	1				
34		Red Wheels Cover	1				
34		Black Wheels Cover	1				
34	49961	Yellow Wheels Cover	1				
34		Orange Wheels Cover	1				
35		Plate	1				
36		Screw	2				
56		Cover	1				
57		Washer	4				
58		Screw	4				
59		Cover	1				

BODY WORK

VT 848



STEERING



EXPLODED PARTS LIST


Year: 2022.
Page(s): 8/32

VT 848

No	Code	Name	Qty	No	Code	Name	Qty
1		Screw	1	63		Valve	2
2		Washer	1	64		Wheel Assy	2
3		Washer	1	66	053601	Washer	2
4	053569	Spacer	1	67	053604	Benzing Ring	2
5	053570	Support	1	68	053584	Hub Cover	2
6	053571	Bushing	1	70		Outfit, Screws	1
7	053572	Steering Column	1				
8		Spring	1				
9		Dowel pin	1				
10	048299	Pinion	1				
11		Screw	2				
12	053573	Support	1				
13	048301	Joint	1				
14	048302	Washer	1				
15	048303	Plate	1				
20	053574	Antifriction Washer	1				
21		Pin	1				
22	053576	Washer	1				
23	053577	Pin	1				
24	048300	Steering Sector	1				
25	053578	Plate	1				
26		Elastic Washer	1				
27	048325	Elastic Disc	1				
28		Nut	2				
29		Nut	2				
30	053579	Steering Rod	1				
32		Nut	2				
34	072012	Lever	1				
35	071883	Screw	1				
36		Washer	2				
37	071881	Nut	1				
38		Pin	2				
39	040574	Tie Rod	1				
40	053580	Bushing	2				
41	53581	Right Stub Axle	1				
42	53582	Left Stub Axle	1				
43	042472	Nut	2				
45	046587	Equalizer With Bush And Lubricator	1				
46		Grease Dispenser	2				
47		Bushing	4				
48	053604	Benzing Ring	1				
51		Screw	1				
52		Washer	2				
53		Spacer	1				
54		Grower	1				
55		Nut	1				
61	048304	Bearing	4				
62		Tyre	2				

STEERING

VT 848



BRAKE AND GEARBOX CONTROLS



EXPLODED PARTS LIST


Year: 2022.
Page(s): 10/32

VT 848

No	Code	Name	Qty	No	Code	Name	Qty
1		Clamp Cover	1				
2		Pedal	1				
3		Screw	4				
4		Plate	2				
5	048305	Rod	1				
6		Washer	4				
7		Plate	1				
8		Antifriction Washer	1				
9		Nut	4				
10		Pin	1				
11	048348	Spacer	1				
12	048309	Pulley	1				
13		Washer	2				
14		Belt Guide Peg	2				
15		Nut	2				
20	071965	Belt	1				
21	048308	Pulley	1				
22		Screw	3				
23		Spacer	1				
24		Washer	3				
25		Nut	3				
26		Nut	1				
27		Washer	1				
28	040294	Pulley	1				
29		Lever	1				
30		Screw	1				
31		Bushing	2				
32	053590	Spacer	1				
33		Nut	1				
34	053591	Spring	1				
35	048306	Tie Rod	1				
36		Nut	1				
37		Cotter Pin	1				
38	048347	Crown Fastener	1				
41	048307	Knob	1				
42	053592	Rod	1				
43	053593	Hook	1				
44	053594	Pin	1				
45		Nut	1				
46		Spring	1				
47		Washer	1				
51		Spacer	2				
52	071962	Pulley	2				

BRAKE AND GEARBOX CONTROLS

VT 848



TRANSMISSION



EXPLODED PARTS LIST


Year: 2022.
Page(s): 12/32

VT 848

No	Code	Name	Qty	No	Code	Name	Qty
1	048313	Knob	1				
2	048312	Lever	1				
3	053636	Clamp	1				
4		Screw	1				
5	053637	Spring	1				
6		Nut	1				
7		Pin	1				
8	053574	Antifriction Washer	1				
9		Nut	1				
10		Washer	1				
11		Nut	1				
12	048314	Rod	1				
13		Nut	1				
14		Washer	1				
15		Lever	1				
16		Cotter Pin	1				
17		Screw	1				
18		Washer	1				
19		Washer	1				
21		Screw	4				
22		Washer	4				
23	048311	Transaxle PEERLESS MST 205-535G	1				
24		Nut	4				
25	036702	Pulley	1				
26		Key	1				
27		Seeger	1				
28	056602	Belt Guide	1				
29		Screw	2				
30	056603	Belt Guide	1				
31		Screw	4				
32		Support	2				
35		Support	1				
36		Screw	2				
37		Nut	2				
39		Screw	2				
40		Nut	2				
41	053601	Washer	2				
43	053601	Washer	6				
44	053604	Benzing Ring	2				
45	053584	Hub Cover	2				
46		Wheel Assy	2				
47		Valve	2				
49		Washer	2				
50		Faston Terminal	2				

TRANSMISSION

VT 848



CUTTING PLATE LIFTING



EXPLODED PARTS LIST


Year: 2022.
Page(s): 14/32

VT 848

[illegible]

CUTTING PLATE LIFTING

VT 848



CUTTING PLATE



EXPLODED PARTS LIST



Year: 2022.
Page(s): 16/32

VT 848

No	Code	Name	Qty	No	Code	Name	Qty
1	048322	Cutting Plate Black	1	50		Nut	2
2	048321	Water Hose Connection	2	51	48320	Equalizer Rod	2
3		Or Ring	2	52		Washer	8
4	046383	Flange Assy	1	53		Nut	4
5		Shaft	1	60	048324	Screw	1
6	046679	Bearing	4	61	048323	Screw	1
7	46880	Dust Cover Disc	2	62	048326	Washer	2
8	046681	Seeger	2	63	048325	Elastic Disc	2
9	048318	Flange Assy	1	64	033615	Right Blade, Winged	1
10		Shaft	1	65	037742	Left Blade, Winged	1
11	032052	Drive Belt	1	66	033616	Blade Holder	2
12	36705	Pulley	2	66		Blade Holder	2
13	053621	Screw	2	67	033619	Key	2
14		Washer	2	71	033613	Right Mulching Blade	1
15		Washer	2	72	033614	Left Mulching Blade	1
16	053622	Feather	2	75		Screw	3
17		Screw	6	76	053640	Deflector	1
18		Nut	6	77		Nut	4
20		Bracket	1	78	053641	Support	1
21		Screw	1	79		Washer	4
22		Washer	1	80		Screw	1
23	053615	Seeger	1	81		Mulching Blades	1
24		Bearing	1	82		Winged Blades	1
25	036704	Pulley	1				
26	053617	Spacer	1				
27		Lever	1				
28		Nut	1				
29		Nut	1				
30		Washer	1				
31	053618	Bushing	1				
32	037786	Wire	1				
33	053620	Spacer	1				
34	048326	Washer	1				
35		Nut	1				
36	057150	Electromagnetic Clutch	1				
36		Electromagnetic Clutch	1				
37		Washer	1				
38		Screw	1				
39	53639	Spring	1				
41	053624	Screw	2				
42		Washer	2				
43		Pulley	2				
44		Spacer	2				
45		Nut	2				
46		Screw	2				
47		Washer	2				
48		Spacer	2				
49	071981	Anti Scalp Wheel Ø 90	2				

CUTTING PLATE

VT 848



COMPLETE CUTTING PLATE



EXPLODED PARTS LIST


Year: 2022.
Page(s): 18/32

VT 848

[illegible]

COMPLETE CUTTING PLATE

VT 848



BELT PROTECTION



EXPLODED PARTS LIST


Year: 2022.
Page(s): 20/32

VT 848

[illegible]

BELT PROTECTION

VT 848



GRASSCATCHER



EXPLODED PARTS LIST

Year: 2022.


Page(s): 22/32

VT 848

[illegible]

GRASSCATCHER

VT 848



ENGINE ST 12-14-16 HP



EXPLODED PARTS LIST

Year: 2022.


Page(s): 24/32

VT 848

[illegible]


ENGINE ST 12-14-16 HP

VT 848



ELECTRICAL PARTS

VT 848





EXPLODED PARTS LIST


Year: 2022.
Page(s): 28/32

VT 848

[illegible]

SAFETY LABELS

VT 848



OPTIONALS ON REQUEST



EXPLODED PARTS LIST


Year: 2022.
Page(s): 30/32

VT 848

[illegible]

OPTIONALS ON REQUEST

VT 848



SEAT AND STEERING WHEEL



EXPLODED PARTS LIST

Year: 2022.
Page(s): 32/32

VT 848

[illegible]

SEAT AND STEERING WHEEL