




DAEWOO

POWER PRODUCTS

DARLM2500i


ROBOT LAWN MOWER




EXPLODED VIEW / DESPIECE / VUE ÉCLATÉE

www.daewoopowerproducts.com

Manufactured under license of Daewoo International Corporation, Korea
Fabricado bajo licencia de Daewoo International Corporation, Corea




PART NO.	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
1	DA04-RM0311-000306-01-001	Robotic Lawnmower	1
2	DA04-RM0311-000306-01-002	Charging Stat ion	1




PART NO.	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
1	DA04-RM0311-000306-02-003	Surface shell	1
2	DA04-RM0311-000306-02-004	Inner upper shell	1
3	DA04-RM0311-000306-02-005	Inner lower shell	1





PART NO.	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
1	DA04-RM0311-000306-03-006	Upper surface shell	1
2	DA04-RM0311-000306-03-007	Tail trim	1
3	DA04-RM0311-000306-03-008	Screw PB4*12mm	5
4	DA04-RM0311-000306-03-009	Nail Rod	2
5	DA04-RM0311-000306-03-010	Flip spring	2
6	DA04-RM0311-000306-03-011	hinge mount	2
7	DA04-RM0311-000306-03-012	Screw PB3.0*8	12
8	DA04-RM0311-000306-03-013	Cut height knob cover	1
9	DA04-RM0311-000306-03-014	Controller cover	1
10	DA04-RM0311-000306-03-015	Rubber buffer strip	1
11	DA04-RM0311-000306-03-016	Lower surface shell	1
12	DA04-RM0311-000306-03-017	STOP Button	1
13	DA04-RM0311-000306-03-018	Pressing Spring_Front	2
14	DA04-RM0311-000306-03-019	Press ing Spring_Rear	1
15	DA04-RM0311-000306-03-020	window bolt	2
16	DA04-RM0311-000306-03-021	W indow p in press ing spr ing	2
17	DA04-RM0311-000306-03-022	Button rotarod(R)	1
18	DA04-RM0311-000306-03-023	Screw CB4*8/head9mm	2
19	DA04-RM0311-000306-03-024	Button rotarod(L)	1
20	DA04-RM0311-000306-03-025	W indow p in press ing p late	1
21	DA04-RM0311-000306-03-026	Magnet/thicknessφ8*2	1
22	DA04-RM0311-000306-03-027	Button cam ring	1
23	DA04-RM0311-000306-03-028	Rain sensor	1
24	DA04-RM0311-000306-03-029	Ra in sens ing cover	1
25	DA04-RM0311-000306-03-030	Dacromet screw PB4*12	8



PART NO.	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
26	DA04-RM0311-000306-04-031	Bozi hat	4
27	DA04-RM0311-000306-04-032	Front wave head	2
28	DA04-RM0311-000306-04-033	Front swing dust cover	2
29	DA04-RM0311-000306-04-034	Dustproof upper gland	2
30	DA04-RM0311-000306-04-035	Screw PB3.0*8	14
31	DA04-RM0311-000306-04-036	Dustproof lower gland	2
32	DA04-RM0311-000306-04-037	Screw KB3*10mm	8
33	DA04-RM0311-000306-04-038	Front swing rod gland	2
34	DA04-RM0311-000306-04-039	Swing tower spring	2
35	DA04-RM0311-000306-04-040	Front swing cover	2
36	DA04-RM0311-000306-04-041	Front upper casing	2
37	DA04-RM0311-000306-04-042	Front swing bar	2
38	DA04-RM0311-000306-04-043	Screw PB4*18mm	4
39	DA04-RM0311-000306-04-044	Magnet/thicknessφ8*3	3
40	DA04-RM0311-000306-04-045	Magnet cover	3
41	DA04-RM0311-000306-04-046	cut height knob	1
42	DA04-RM0311-000306-04-047	Knob O-ring	1
43	DA04-RM0311-000306-04-048	R-clamp	1
44	DA04-RM0311-000306-04-049	screw CB4*8/ head9mm	1
45	DA04-RM0311-000306-04-050	Hall plate	2
46	DA04-RM0311-000306-04-051	Front hall wire	1
47	DA04-RM0311-000306-04-052	Membrane key	1
48	DA04-RM0311-000306-04-053	Key platform	1
49	DA04-RM0311-000306-04-054	Sealing ring	1
50	DA04-RM0311-000306-04-055	Display	1
51	DA04-RM0311-000306-04-056	Screw PB4*14mm	31
52	DA04-RM0311-000306-04-057	Inner upper she l l	1
53	DA04-RM0311-000306-04-058	Rear hall wire	1
54	DA04-RM0311-000306-04-059	Display wire	1
55	DA04-RM0311-000306-04-060	Rear wave head	2
56	DA04-RM0311-000306-04-061	Rear swing rod gland	2
57	DA04-RM0311-000306-04-062	Rear buffer rubber	2
58	DA04-RM0311-000306-04-063	Rear swing rod cover	2
59	DA04-RM0311-000306-04-064	Rear lower sw ing bar	2



PART NO.	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
60	DA04-RM0311-000306-05-065	Screw PB3.0*8	20
61	DA04-RM0311-000306-05-066	Tooth box gland	1
62	DA04-RM0311-000306-05-067	Transmission teeth	1
63	DA04-RM0311-000306-05-068	Double tooth	1
64	DA04-RM0311-000306-05-069	Start tooth	1
65	DA04-RM0311-000306-05-070	Screw CB4*8 head 9mm	5
66	DA04-RM0311-000306-05-071	Buckle	1
67	DA04-RM0311-000306-05-072	Lift seat cover	1
68	DA04-RM0311-000306-05-073	Screw PB4*12mm	31
69	DA04-RM0311-000306-05-074	Lifting seat sealing strip	1
70	DA04-RM0311-000306-05-075	Motor wire SR	2
71	DA04-RM0311-000306-05-076	L i f t i n g c y l i n d e r c o v e r	1
72	DA04-RM0311-000306-05-077	L i f t i n g c y l i n d e r s e a l i n g s t r i p	1
73	DA04-RM0311-000306-05-078	Cutting motor	1
74	DA04-RM0311-000306-05-079	L i f t i n g c y l i n d e r c o v e r	1
75	DA04-RM0311-000306-05-080	PBM4*10 Big head dish pattern	7
76	DA04-RM0311-000306-05-081	Cutting disk connector	1
77	DA04-RM0311-000306-05-082	Front right wheel bow	1
78	DA04-RM0311-000306-05-083	Front wheel axle cover	2
79	DA04-RM0311-000306-05-084	Front wheel (upper)	2
80	DA04-RM0311-000306-05-085	Front wheel bearing-13	4
81	DA04-RM0311-000306-05-086	Front wheel bushing	2
82	DA04-RM0311-000306-05-087	ont wheel bearing-19	2
83	DA04-RM0311-000306-05-088	Front wheel meson	4
84	DA04-RM0311-000306-05-089	Clip ring	4
85	DA04-RM0311-000306-05-090	Front wheel(lower)	2
86	DA04-RM0311-000306-05-091	Rotating bushing	2
87	DA04-RM0311-000306-05-092	Front wheel bearing-17	2
88	DA04-RM0311-000306-05-093	Rotating end cap	2
89	DA04-RM0311-000306-05-094	Motor O-ring	2
90	DA04-RM0311-000306-05-095	Rear wheel drive	2
91	DA04-RM0311-000306-05-096	Rear wheel core(Inner)	2
92	DA04-RM0311-000306-05-097	Ba lance we igh t R i n g	2
93	DA04-RM0311-000306-05-098	Rear wheel skin	2
94	DA04-RM0311-000306-05-099	Rear whee l c o r e (o u t e r)	2
95	DA04-RM0311-000306-05-100	Screw M8*14	2
96	DA04-RM0311-000306-05-101	Battery cover sealing strip	1
97	DA04-RM0311-000306-05-102	Battery	1
98	DA04-RM0311-000306-05-103	Battery cover	1
99	DA04-RM0311-000306-05-104	Upgrade Wire	1
100	DA04-RM0311-000306-05-105	Upgrade board	1
101	DA04-RM0311-000306-05-106	Mother board	1
102	DA04-RM0311-000306-05-107	Battery coil	1
103	DA04-RM0311-000306-05-108	Battery transfer wire	1
104	DA04-RM0311-000306-05-109	Inner shell bottom	1
105	DA04-RM0311-000306-05-110	Charging wire protection coil	1
106	DA04-RM0311-000306-05-111	Rain sense wire protection coil	1
107	DA04-RM0311-000306-05-112	Screw rod	1
108	DA04-RM0311-000306-05-113	Nylon twist clamp	2
109	DA04-RM0311-000306-05-114	Left front wheel bow	1
110	DA04-RM0311-000306-05-115	Charging sheet shaft	2
111	DA04-RM0311-000306-05-116	Charging torsion spring	2
112	DA04-RM0311-000306-05-117	Charging sheet	2
113	DA04-RM0311-000306-05-118	Charging device cover	2
114	DA04-RM0311-000306-05-119	Copper spring washer	2
115	DA04-RM0311-000306-05-120	Screw PM3*5mm	2
116	DA04-RM0311-000306-05-121	Lifting rail	2
117	DA04-RM0311-000306-05-122	Cast Iron Block-R	1
118	DA04-RM0311-000306-05-123	Cast Iron B lock-L	1
119	DA04-RM0311-000306-05-124	sealing strip	1
120	DA04-RM0311-000306-05-125	Charging cable	1
121	DA04-RM0311-000306-05-126	Inductance board	1
122	DA04-RM0311-000306-05-127	inner rain sensor wire	1
123	DA04-RM0311-000306-05-128	Upgrade port plug	1
124	DA04-RM0311-000306-05-129	Protection P late	1
125	DA04-RM0311-000306-05-130	Cutting b lades	3



PART NO.	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
128	DA04-RM0311-000306-06-131	Charging dock base	1
129	DA04-RM0311-000306-06-132	Charging dock bottom cover	1
130	DA04-RM0311-000306-06-133	Screw PB4*12mm	10
131	DA04-RM0311-000306-06-134	PCB box cover	1
132	DA04-RM0311-000306-06-135	Clamp O type ring	1
133	DA04-RM0311-000306-06-136	LED sealing plug	1
134	DA04-RM0311-000306-06-137	Sealing strip	1
135	DA04-RM0311-000306-06-138	Audio clamp	1
136	DA04-RM0311-000306-06-139	Waterproof connector seat	1
137	DA04-RM0311-000306-06-140	Round stick charging head	2
138	DA04-RM0311-000306-06-141	Screw PB4*14mm	2
139	DA04-RM0311-000306-06-142	Charg ing p i le par ts	1
140	DA04-RM0311-000306-06-143	Charging rubber pad	1
141	DA04-RM0311-000306-06-144	Charging dock PCB board	1
142	DA04-RM0311-000306-06-145	Screw PB3*8mm	8
143	DA04-RM0311-000306-06-146	Nails for charging station	4
144	DA04-RM0311-000306-06-147	Power Adaptor	1
145	DA04-RM0311-000306-06-148	Allen Key	1
146	DA04-RM0311-000306-06-149	Boundary wire	1
147	DA04-RM0311-000306-06-150	Pegs for boundary wire	100
148	DA04-RM0311-000306-06-151	PVC hollow pipe	1
149	DA04-RM0311-000306-06-152	Anti-collision cable	1
150	DA04-RM0311-000306-06-153	Sealing plug	1