


VBV 230 E



Engine



EXPLODED PARTS LIST

Year: 2018


Page(s): 2/4

VBV 230 E

No	Code	Name	Qty	No	Code	Name	Qty
1	055092	SCREW	1		055110	FRONT HALF CRANK CASE (this is next to positions 14 and 15)	1
2	055093	OUTSIDE COVER	1				
3	055094	FILTER NET	1				
4		SCREW	1				
5		M5X65	2				
6		CHOKE	1				
7		INSIDE COVER	1				
8		CHOKE HANDLE	1				
9	055095	CARBURETOR	1				
10	055096	GASKET	1				
11		SCREW	1				
12	055097	ADMITTING PIPE	1				
13	051991	GASKET	1				
14	010860	OIL SEAL	2				
15		SCREW	1				
16	051980	CRANK CASE GASKET	1				
17		PIN B4*8	2				
18	051979	BEARING 6001-P6	2				
19	055098	NEEDLE BEARING	1				
20	055099	CRANK SHAFT COMP	1				
21	051978	KEY	1				
22	051976	PISTON	1				
23	055100	PISTON PIN	1				
24	055101	PISTON PIN CIRCLIP	2				
25	051975	PISTON RING	2				
26	051974	GASKET	1				
27	051973	CYLINDER	1				
28		M5X16	4				
29	052000	PLUG	1				
30	055102	MUFFLER GASKET	1				
31	055103	MUFFLER	1				
32	055104	MUFFLER COVER	1				
33		SCREW M5X55	1				
34	052002	CAP	1				
35	052001	SPRING	1				
36		6*60 PIPE	1				
37	051985	IGNITION COIL COMP	1				
38	055105	INSIDE COVER ASSY. (4-8)	1				
39	055106	SCREW M6*16	2				
40	051987	START REEL	1				
41	055107	NUT 8	1				
42		WASHER 8	1				
43		WASHER 8	1				
44	055108	FLY WHEEL	1				
45		SCREW M4*20	2				
46		SCREW M5*16	3				
47	051984	REAR HALF CRANK CASE	1				
48	055109	GASKET	1				

Engine

VBV 230 E





EXPLODED PARTS LIST

Year: 2018

Page(s): 4/4

VBV 230 E

No	Code	Name	Qty	No	Code	Name	Qty
1	036787	PIPE (2)	1	49		SCREW M5X12	3
2		PIPE (1)	1	50	055088	COLECTING BAG	1
3		SCREW M5X10	1	51	055089	BENT PIPE	1
4		SCREW M5X16	1	52	055090	BLOWING PIPE I	1
5		WASHER FI 5	1	53	055091	BLOWING PIPE II	1
6	055069	PROTECTIION	1				
7	055070	SPRING SCREW	1				
8	055071	SPRING	1				
9		SCREW M5X16	11				
10	055072	NUT M8X1 LH	1				
11	055073	COMMINUTE BOARD	1				
12		SCREW M5X20	1				
13	055074	IMPELER	1				
14	055075	HANDLE COVER (2)	1				
15	055076	STOP SWITCH	1				
16	055077	VALUTE CASE	1				
17	055078	BOTTOM HANDLE	1				
18		STOP WIRE	1				
19	055079	CONTROL HANDLE	1				
20	055080	FUEL THROTTLE	1				
21		NUT M5	1				
22		NUT M5	1				
23	055081	HANDLE	1				
24		WASHER	1				
25	055082	CONTROL HANDLE	1				
26		SCREW M5X25	1				
27	055083	HANDLE COVER (1)	1				
28		FUEL TANK	1				
29	010871	FILTER	1				
30	028392	FUEL PIPE	1				
31		FUEL PIPE	1				
32	055084	PLUG	1				
33		CHAIN	1				
34		AIR VALVE	1				
35		END COVER	1				
36		SEALING WASHER	1				
37		LID	1				
38		FUEL TANK LID	1				
39	055085	FUEL TANK LID ASSY. (33-38)	1				
40	055086	FUEL TANK ASSY. (28-39)	1				
41		SCREW M5X10	1				
42		WASHER FI5	1				
43	016303	ROPE	1				
44		STARTER ROPE REEL	1				
45	016302	RECOIL SPRING	1				
46		STARTER BODY	1				
47		STARTER HANDLE	1				
48	055087	STARTER ASSY	1				

Attachment