




DAEWOO

POWER PRODUCTS

DASC180-38E


ELECTRIC SCARIFIER AND AERATOR



EXPLODED VIEW

www.daewoopowerproducts.com

Manufactured under license of Daewoo International Corporation, Korea
Fabricado bajo licencia de Daewoo International Corporation, Corea



PART NO.	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
1	DA04-ES0111-000301-00-001	WHEEL COVER	2
2	DA04-ES0111-000301-00-002	GASKET	2
3	DA04-ES0111-000301-00-003	PRESSPLATE	2
4	DA04-ES0111-000301-00-004	FRONT WHEEL SPINDLE ASSEMBLY	1
5	DA04-ES0111-000301-00-005	WHEEL	2
6	DA04-ES0111-000301-00-006	FRONT DECORATIVE PANEL	1
7	DA04-ES0111-000301-00-007	FILTER SPONGE NO I	1
8	DA04-ES0111-000301-00-008	FILTER SPONGE NO II	1
9	DA04-ES0111-000301-00-009	FILTER SPONGE NO III	1
10	DA04-ES0111-000301-00-010	NUT	1
11	DA04-ES0111-000301-00-011	PRESSPLATE	1
12	DA04-ES0111-000301-00-012	BREAKWIND	1
13	DA04-ES0111-000301-00-013	HOUSING COVER	1
14	DA04-ES0111-000301-00-014	HOUSING HANDLE	1
15	DA04-ES0111-000301-00-015	GRASS BAG FIXING PIN	1
16	DA04-ES0111-000301-00-016	SPRING	1
17	DA04-ES0111-000301-00-017	GRASS BAG COVER	1
18	DA04-ES0111-000301-00-018	TORSION SPRING FIXING PIN	1
19	DA04-ES0111-000301-00-019	PROTECTOR AMG GPTC	1
20	DA04-ES0111-000301-00-020	SANDBAG	1
21	DA04-ES0111-000301-00-021	BASE	1
22	DA04-ES0111-000301-00-022	BACK WHEEL SPINDLE	2
23	DA04-ES0111-000301-00-023	SCREW ST	2
24	DA04-ES0111-000301-00-024	WHEEL	2
25	DA04-ES0111-000301-00-025	GASKET	2
26	DA04-ES0111-000301-00-026	WHEEL COVER	2
27	DA04-ES0111-000301-00-027	NUT	1
28	DA04-ES0111-000301-00-028	NUT	1
29	DA04-ES0111-000301-00-029	NUT	1
30	DA04-ES0111-000301-00-030	NUT	1
31	DA04-ES0111-000301-00-031	EXTERNAL HEXAGONAL LOCKING NUT	1
32	DA04-ES0111-000301-00-032	GASKET	1
33	DA04-ES0111-000301-00-033	PRESS PLATE	1
34	DA04-ES0111-000301-00-034	BLADE QUICK RELEASE KNOB & SCREWS	1
35	DA04-ES0111-000301-00-036	DEPTH ADJUST HANDLE RIGHT	1
36	DA04-ES0111-000301-00-037	DEPTH ADJUST HANDLE LEFT	1
37	DA04-ES0111-000301-00-038	SCREW	2
38	DA04-ES0111-000301-00-039	PIN	4
39	DA04-ES0111-000301-00-040	GRASS COLLECT FRAME	1
40	DA04-ES0111-000301-00-041	GRASS COLLECT BAG	1
41	DA04-ES0111-000301-00-042	SCREW	21
42	DA04-ES0111-000301-00-043	SCREW	3
43	DA04-ES0111-000301-00-044	KNOB	4
44	DA04-ES0111-000301-00-045	NUT	4
45	DA04-ES0111-000301-00-046	GASKET	4
46	DA04-ES0111-000301-00-047	ROD NOII	1
47	DA04-ES0111-000301-00-048	SCREW	4
48	DA04-ES0111-000301-00-049	CABLE STRAIN RELIEF	1
49	DA04-ES0111-000301-00-050	CABLE CLAMP	1

50	DA04-ES0111-000301-00-051	NO ROD SEAT	2
51	DA04-ES0111-000301-00-052	NO ROD	2
52	DA04-ES0111-000301-00-053	SCREW	4
53	DA04-ES0111-000301-00-054	KNOB	2
54	DA04-ES0111-000301-00-055	SCREW	2
100	DA04-ES0111-000301-00-056	MOTOR ASSEMBLY	1
101	DA04-ES0111-000301-00-057	RING	1
102	DA04-ES0111-000301-00-058	MOTOR FAN	1
103	DA04-ES0111-000301-00-059	SCREW	2
104	DA04-ES0111-000301-00-060	CARBON BRUSH	2
105	DA04-ES0111-000301-00-061	CARBON BRUSH HOLDER	2
106	DA04-ES0111-000301-00-062	HOUSING	1
107	DA04-ES0111-000301-00-063	STATOR ASSEMBLY	1
107-1	DA04-ES0111-000301-00-064	INDUCTANCE	2
108	DA04-ES0111-000301-00-065	SCREW	2
109	DA04-ES0111-000301-00-066	GASKET	1
110	DA04-ES0111-000301-00-067	BEARING	1
111	DA04-ES0111-000301-00-068	ROTOR ASSEMBLY	1
112	DA04-ES0111-000301-00-069	BEARING	2
113	DA04-ES0111-000301-00-070	GASKET	2
114	DA04-ES0111-000301-00-071	WOOL FELT	1
115	DA04-ES0111-000301-00-072	GEAR BOX	1
116	DA04-ES0111-000301-00-073	BEARING HK	1
117	DA04-ES0111-000301-00-074	RING	1
118	DA04-ES0111-000301-00-075	WHEEL	1
119	DA04-ES0111-000301-00-076	BERING	1
120	DA04-ES0111-000301-00-077	CENTRE FRAME	1
121	DA04-ES0111-000301-00-078	SCREW	3
122	DA04-ES0111-000301-00-079	SCREW	3
123	DA04-ES0111-000301-00-080	OUTPUT AXIS	1
124	DA04-ES0111-000301-00-081	BELT	1
125	DA04-ES0111-000301-00-082	CENTRE FRAME COVER	1
126	DA04-ES0111-000301-00-083	NUT	1
127	DA04-ES0111-000301-00-084	BEARING	1
128	DA04-ES0111-000301-00-085	WHEEL	1
129	DA04-ES0111-000301-00-086	BEARING	1
130	DA04-ES0111-000301-00-087	GASKET	1
131	DA04-ES0111-000301-00-088	AXIS	1
132	DA04-ES0111-000301-00-089	AXIS	1
133	DA04-ES0111-000301-00-090	SCREW	3
200	DA04-ES0111-000301-00-093	SWITCH ASSEMBLY	1
201	DA04-ES0111-000301-00-094	TRIGGER SEAT LEFT	1
202	DA04-ES0111-000301-00-095	SPRING	1
203	DA04-ES0111-000301-00-096	WIRE CONNECTED ROD	1
204	DA04-ES0111-000301-00-097	TRIGGER SEAT RIGHT	1
205	DA04-ES0111-000301-00-098	SCREW	2
206	DA04-ES0111-000301-00-099	SWITCH BOX PRESSPLATE	1
207	DA04-ES0111-000301-00-100	SWITCH BOX LEFT	1
208	DA04-ES0111-000301-00-101	WIRE	1
209	DA04-ES0111-000301-00-102	PLUG	1

210	DA04-ES0111-000301-00-103	CABLE SLEEVE	1
211	DA04-ES0111-000301-00-104	SWITCH RESET SHRAPNEL	2
212	DA04-ES0111-000301-00-105	ROCKER SWITCH	1
213	DA04-ES0111-000301-00-106	SPRING	1
214	DA04-ES0111-000301-00-107	TRIGGER	1
215	DA04-ES0111-000301-00-108	CAPACITANCE	1
216	DA04-ES0111-000301-00-109	SWITCH BUTTON	1
217	DA04-ES0111-000301-00-110	SWITCH BOX	1
218	DA04-ES0111-000301-00-111	ROD NO III	1
219	DA04-ES0111-000301-00-112	SPONGE TUBE	1
220	DA04-ES0111-000301-00-113	WIRE TRIGGER	1
300	DA04-ES0111-000301-00-118	SCARIFIER ASSEMBLY EIGHT BLADE	1
301	DA04-ES0111-000301-00-119	Connecting shaft head	1
302	DA04-ES0111-000301-00-120	Shaft head gasket	1
303	DA04-ES0111-000301-00-121	Blade iron bushing short	1
304	DA04-ES0111-000301-00-122	Elastic cylindrical pin	1
305	DA04-ES0111-000301-00-123	128 blades	8
306	DA04-ES0111-000301-00-124	8 blade plastic bushing	7
307	DA04-ES0111-000301-00-125	Blade iron bushing length	1
308	DA04-ES0111-000301-00-126	Dust cover left	1
309	DA04-ES0111-000301-00-127	Square tube protective gasket	1
310	DA04-ES0111-000301-00-128	Blade square tube shaft	1
400	DA04-ES0111-000301-00-131	AERATOR ASSEMBLY	1
401	DA04-ES0111-000301-00-132	Claw spring holder cover	13
402	DA04-ES0111-000301-00-133	Claw spring holder	12
403	DA04-ES0111-000301-00-134	claw spring	24
404	DA04-ES0111-000301-00-135	Grass combing blade square tube shaft	1