




**DAEWOO**  
POWER PRODUCTS

# DASC180-38E


ELECTRIC SCARIFIER AND AERATOR



**EXPLODED VIEW**

[www.daewoopowerproducts.com](http://www.daewoopowerproducts.com)

Manufactured under license of Daewoo International Corporation, Korea  
Fabricado bajo licencia de Daewoo International Corporation, Corea



PART NO.	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
1	DA04-ES0111-000301-00-001	WHEEL COVER	2
2	DA04-ES0111-000301-00-002	GASKET	2
3	DA04-ES0111-000301-00-003	PRESSPLATE	2
4	DA04-ES0111-000301-00-004	FRONT WHEEL SPINDLE ASSEMBLY	1
5	DA04-ES0111-000301-00-005	WHEEL	2
6	DA04-ES0111-000301-00-006	FRONT DECORATIVE PANEL	1
7	DA04-ES0111-000301-00-007	FILTER SPONGE NO I	1
8	DA04-ES0111-000301-00-008	FILTER SPONGE NO II	1
9	DA04-ES0111-000301-00-009	FILTER SPONGE NO III	1
10	DA04-ES0111-000301-00-010	NUT	1
11	DA04-ES0111-000301-00-011	PRESSPLATE	1
12	DA04-ES0111-000301-00-012	BREAKWIND	1
13	DA04-ES0111-000301-00-013	HOUSING COVER	1
14	DA04-ES0111-000301-00-014	HOUSING HANDLE	1
15	DA04-ES0111-000301-00-015	GRASS BAG FIXING PIN	1
16	DA04-ES0111-000301-00-016	SPRING	1
17	DA04-ES0111-000301-00-017	GRASS BAG COVER	1
18	DA04-ES0111-000301-00-018	TORSION SPRING FIXING PIN	1
19	DA04-ES0111-000301-00-019	PROTECTOR AMG GPTC	1
20	DA04-ES0111-000301-00-020	SANDBAG	1
21	DA04-ES0111-000301-00-021	BASE	1
22	DA04-ES0111-000301-00-022	BACK WHEEL SPINDLE	2
23	DA04-ES0111-000301-00-023	SCREW ST	2
24	DA04-ES0111-000301-00-024	WHEEL	2
25	DA04-ES0111-000301-00-025	GASKET	2
26	DA04-ES0111-000301-00-026	WHEEL COVER	2
27	DA04-ES0111-000301-00-027	NUT	1
28	DA04-ES0111-000301-00-028	NUT	1
29	DA04-ES0111-000301-00-029	NUT	1
30	DA04-ES0111-000301-00-030	NUT	1
31	DA04-ES0111-000301-00-031	EXTERNAL HEXAGONAL LOCKING NUT	1
32	DA04-ES0111-000301-00-032	GASKET	1
33	DA04-ES0111-000301-00-033	PRESS PLATE	1
34	DA04-ES0111-000301-00-034	BLADE QUICK RELEASE KNOB & SCREWS	1
35	DA04-ES0111-000301-00-036	DEPTH ADJUST HANDLE RIGHT	1
36	DA04-ES0111-000301-00-037	DEPTH ADJUST HANDLE LEFT	1
37	DA04-ES0111-000301-00-038	SCREW	2
38	DA04-ES0111-000301-00-039	PIN	4
39	DA04-ES0111-000301-00-040	GRASS COLLECT FRAME	1
40	DA04-ES0111-000301-00-041	GRASS COLLECT BAG	1
41	DA04-ES0111-000301-00-042	SCREW	21
42	DA04-ES0111-000301-00-043	SCREW	3
43	DA04-ES0111-000301-00-044	KNOB	4
44	DA04-ES0111-000301-00-045	NUT	4
45	DA04-ES0111-000301-00-046	GASKET	4
46	DA04-ES0111-000301-00-047	ROD NOII	1
47	DA04-ES0111-000301-00-048	SCREW	4
48	DA04-ES0111-000301-00-049	CABLE STRAIN RELIEF	1
49	DA04-ES0111-000301-00-050	CABLE CLAMP	1

50	DA04-ES0111-000301-00-051	NO ROD SEAT	2
51	DA04-ES0111-000301-00-052	NO ROD	2
52	DA04-ES0111-000301-00-053	SCREW	4
53	DA04-ES0111-000301-00-054	KNOB	2
54	DA04-ES0111-000301-00-055	SCREW	2
100	DA04-ES0111-000301-00-056	MOTOR ASSEMBLY	1
101	DA04-ES0111-000301-00-057	RING	1
102	DA04-ES0111-000301-00-058	MOTOR FAN	1
103	DA04-ES0111-000301-00-059	SCREW	2
104	DA04-ES0111-000301-00-060	CARBON BRUSH	2
105	DA04-ES0111-000301-00-061	CARBON BRUSH HOLDER	2
106	DA04-ES0111-000301-00-062	HOUSING	1
107	DA04-ES0111-000301-00-063	STATOR ASSEMBLY	1
107-1	DA04-ES0111-000301-00-064	INDUCTANCE	2
108	DA04-ES0111-000301-00-065	SCREW	2
109	DA04-ES0111-000301-00-066	GASKET	1
110	DA04-ES0111-000301-00-067	BEARING	1
111	DA04-ES0111-000301-00-068	ROTOR ASSEMBLY	1
112	DA04-ES0111-000301-00-069	BEARING	2
113	DA04-ES0111-000301-00-070	GASKET	2
114	DA04-ES0111-000301-00-071	WOOL FELT	1
115	DA04-ES0111-000301-00-072	GEAR BOX	1
116	DA04-ES0111-000301-00-073	BEARING HK	1
117	DA04-ES0111-000301-00-074	RING	1
118	DA04-ES0111-000301-00-075	WHEEL	1
119	DA04-ES0111-000301-00-076	BERING	1
120	DA04-ES0111-000301-00-077	CENTRE FRAME	1
121	DA04-ES0111-000301-00-078	SCREW	3
122	DA04-ES0111-000301-00-079	SCREW	3
123	DA04-ES0111-000301-00-080	OUTPUT AXIS	1
124	DA04-ES0111-000301-00-081	BELT	1
125	DA04-ES0111-000301-00-082	CENTRE FRAME COVER	1
126	DA04-ES0111-000301-00-083	NUT	1
127	DA04-ES0111-000301-00-084	BEARING	1
128	DA04-ES0111-000301-00-085	WHEEL	1
129	DA04-ES0111-000301-00-086	BEARING	1
130	DA04-ES0111-000301-00-087	GASKET	1
131	DA04-ES0111-000301-00-088	AXIS	1
132	DA04-ES0111-000301-00-089	AXIS	1
133	DA04-ES0111-000301-00-090	SCREW	3
200	DA04-ES0111-000301-00-093	SWITCH ASSEMBLY	1
201	DA04-ES0111-000301-00-094	TRIGGER SEAT LEFT	1
202	DA04-ES0111-000301-00-095	SPRING	1
203	DA04-ES0111-000301-00-096	WIRE CONNECTED ROD	1
204	DA04-ES0111-000301-00-097	TRIGGER SEAT RIGHT	1
205	DA04-ES0111-000301-00-098	SCREW	2
206	DA04-ES0111-000301-00-099	SWITCH BOX PRESSPLATE	1
207	DA04-ES0111-000301-00-100	SWITCH BOX LEFT	1
208	DA04-ES0111-000301-00-101	WIRE	1
209	DA04-ES0111-000301-00-102	PLUG	1

210	DA04-ES0111-000301-00-103	CABLE SLEEVE	1
211	DA04-ES0111-000301-00-104	SWITCH RESET SHRAPNEL	2
212	DA04-ES0111-000301-00-105	ROCKER SWITCH	1
213	DA04-ES0111-000301-00-106	SPRING	1
214	DA04-ES0111-000301-00-107	TRIGGER	1
215	DA04-ES0111-000301-00-108	CAPACITANCE	1
216	DA04-ES0111-000301-00-109	SWITCH BUTTON	1
217	DA04-ES0111-000301-00-110	SWITCH BOX	1
218	DA04-ES0111-000301-00-111	ROD NO III	1
219	DA04-ES0111-000301-00-112	SPONGE TUBE	1
220	DA04-ES0111-000301-00-113	WIRE TRIGGER	1
300	DA04-ES0111-000301-00-118	SCARIFIER ASSEMBLY EIGHT BLADE	1
301	DA04-ES0111-000301-00-119	Connecting shaft head	1
302	DA04-ES0111-000301-00-120	Shaft head gasket	1
303	DA04-ES0111-000301-00-121	Blade iron bushing short	1
304	DA04-ES0111-000301-00-122	Elastic cylindrical pin	1
305	DA04-ES0111-000301-00-123	128 blades	8
306	DA04-ES0111-000301-00-124	8 blade plastic bushing	7
307	DA04-ES0111-000301-00-125	Blade iron bushing length	1
308	DA04-ES0111-000301-00-126	Dust cover left	1
309	DA04-ES0111-000301-00-127	Square tube protective gasket	1
310	DA04-ES0111-000301-00-128	Blade square tube shaft	1
400	DA04-ES0111-000301-00-131	AERATOR ASSEMBLY	1
401	DA04-ES0111-000301-00-132	Claw spring holder cover	13
402	DA04-ES0111-000301-00-133	Claw spring holder	12
403	DA04-ES0111-000301-00-134	claw spring	24
404	DA04-ES0111-000301-00-135	Grass combing blade square tube shaft	1