




DAEWOO

POWER PRODUCTS

DAFDWC230


WOOD CHIPPER




EXPLODED VIEW / DESPIECE / VUE ÉCLATÉE

www.daewoopowerproducts.com


Manufactured under license of Daewoo International Corporation, Korea
Fabricado bajo licencia de Daewoo International Corporation, Corea




PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
E01-1	1	DA04-WC0111-000409-01-001	CRANKCASE SUBASSEMBLY.	1
E01-2	1	DA04-WC0111-000409-01-002	SENSOR, ENGINE OIL	1
E01-3	1	DA04-WC0111-000409-01-003	GEAR ASSY, GOVERNOR	1
E01-7	1	DA04-WC0111-000409-01-004	ARM, GOVERNOR	1
E01-8	1	DA04-WC0111-000409-01-005	BOLT, DRAIN PLUG	2
E01-9	1	DA04-WC0111-000409-01-006	FLAT WASHER	2
E01-12	1	DA04-WC0111-000409-01-007	DEEP GROOVE BALL BEARING	1
E02-13	1	DA04-WC0111-000409-01-008	SEAL, OIL	1
E02-15	1	DA04-WC0111-000409-01-009	HEXAGON NUT WITH FLANGE	1
E02-16	1	DA04-WC0111-000409-01-010	FLAT WASHER	1
E02-17	1	DA04-WC0111-000409-01-011	COTTER PIN	1
E02-18	1	DA04-WC0111-000409-01-012	BOLT	2




PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
E02-1	2	DA04-WC0111-000409-02-013	COVER, CRANKCASE	1
E02-2	2	DA04-WC0111-000409-02-014	DEEP GROOVE BALL BEARING	1
E02-3	2	DA04-WC0111-000409-02-015	SEAL, OIL	1
E02-4	2	DA04-WC0111-000409-02-016	GASKET, CRANKCASE	1
E02-5	2	DA04-WC0111-000409-02-017	POSITION PIN	2
E02-6	2	DA04-WC0111-000409-02-018	DIPSTICK SUBASSEMBLY, OIL	1
E02-8	2	DA04-WC0111-000409-02-019	PLUG SUBASSEMBLY, ENGINE OIL	1
E02-9	2	DA04-WC0111-000409-02-020	BOLT	6




PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
E03-1	3	DA04-WC0111-000409-03-021	GASKET, CYLINDER HEAD	1
E03-2	3	DA04-WC0111-000409-03-022	COVER SUBASSEMBLY, CYLINDER HEAD	1
E03-3	3	DA04-WC0111-000409-03-023	CYLINDER HEAD COVER GASKET	1
E03-4	3	DA04-WC0111-000409-03-024	TUBE, BREATHER	1
E03-5	3	DA04-WC0111-000409-03-025	BOLT	4
E03-6	3	DA04-WC0111-000409-03-026	STUD BOLT	2
E03-8	3	DA04-WC0111-000409-03-027	STUD BOLT	2
E03-9	3	DA04-WC0111-000409-03-028	POSITION PIN	2
E03-10	3	DA04-WC0111-000409-03-029	CYLINDER HEAD BOLT	4
E03-11	3	DA04-WC0111-000409-03-030	PLUG, SPARK	1
E03-12	3	DA04-WC0111-000409-03-031	HEAD SUBASSEMBLY, CYLINDER	1




PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
E04-1	4	DA04-WC0111-000409-04-032	CRANKSHAFT ASSY.	1




PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
E05-1	5	DA04-WC0111-000409-05-033	RING ASSY, PISTON	1
E05-2	5	DA04-WC0111-000409-05-034	CLIP, PISTON PIN	2
E05-3	5	DA04-WC0111-000409-05-035	PISTON	1
E05-4	5	DA04-WC0111-000409-05-036	PIN, PISTON	1
E05-5	5	DA04-WC0111-000409-05-037	ROD, CONNECTING	1




PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
E06-1	6	DA04-WC0111-000409-06-038	CAMSHAFT ASSY.	1
E06-3	6	DA04-WC0111-000409-06-039	VALVES SET	1
E06-5	6	DA04-WC0111-000409-06-040	SEAT, VALVE SPRING	2
E06-6	6	DA04-WC0111-000409-06-041	CLAMP, VALVE LOCK	4
E06-7	6	DA04-WC0111-000409-06-042	SPRING, VALVE	2
E06-8	6	DA04-WC0111-000409-06-043	GUIDE, SEAL	1
E06-9	6	DA04-WC0111-000409-06-044	TAPPET, VALVE	2
E06-10	6	DA04-WC0111-000409-06-045	LIFTER, VALVE	2
E06-11	6	DA04-WC0111-000409-06-046	PLATE SUBASSEMBLY, LIFTER STOPPER	1
E06-12	6	DA04-WC0111-000409-06-047	ROCKSHAFT BOLT	2
E06-13	6	DA04-WC0111-000409-06-048	ROCKER, VALVE	2
E06-14	6	DA04-WC0111-000409-06-049	NUT, VALVE ADJUSTING	2
E06-15	6	DA04-WC0111-000409-06-050	NUT, VALVE LOCK	2




PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
E07-1	7	DA04-WC0111-000409-07-051	BOLT	3
E07-2	7	DA04-WC0111-000409-07-052	STARTER ASSY, RECOIL	1




PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
E08-1	8	DA04-WC0111-000409-08-053	SHROUD	1
E08-2	8	DA04-WC0111-000409-08-054	SHROUD, CYLINDER BODY	1
E08-3	8	DA04-WC0111-000409-08-055	SHIELD, LOWER	1
E08-4	8	DA04-WC0111-000409-08-056	PROTECTOR, OIL	1
E08-5	8	DA04-WC0111-000409-08-057	SWITCH SUBASSEMBLY, STOP ENGINE	1
E08-6	8	DA04-WC0111-000409-08-058	BOLT	2
E08-7	8	DA04-WC0111-000409-08-059	BOLT	1
E08-8	8	DA04-WC0111-000409-08-060	COLLAR	1
E08-9	8	DA04-WC0111-000409-08-061	BOLT	1
E08-10	8	DA04-WC0111-000409-08-062	BOLT	4




PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
E09-1	9	DA04-WC0111-000409-09-063	CARBURETOR ASSY.	1
E09-2	9	DA04-WC0111-000409-09-064	AIR CLEANER SEAL GASKET	1
E09-3	9	DA04-WC0111-000409-09-065	CARBURETOR SEAL GASKET	1
E09-4	9	DA04-WC0111-000409-09-066	PLATE, CARBURETOR INSULATOR	1
E09-5	9	DA04-WC0111-000409-09-067	GASKET, CARBURETOR INSULATOR	1




PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
E10-1	10	DA04-WC0111-000409-10-068	NUT, FLYWHEEL	1
E10-2	10	DA04-WC0111-000409-10-069	PULLEY, STARTER	1
E10-3	10	DA04-WC0111-000409-10-070	IMPELLER	1
E10-4	10	DA04-WC0111-000409-10-071	FLYWHEEL SUBASSEMBLY	1
E10-5	10	DA04-WC0111-000409-10-072	COIL, IGNITION	1
E10-6	10	DA04-WC0111-000409-10-073	BOLT	2




PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
E11-1	11	DA04-WC0111-000409-11-074	CONTROL ASSY, THROTTLE	1
E11-2	11	DA04-WC0111-000409-11-075	BOLT	2
E11-3	11	DA04-WC0111-000409-11-076	SPRING, GOVERNOR	1
E11-4	11	DA04-WC0111-000409-11-077	ROD, GOVERNEOR	1
E11-5	11	DA04-WC0111-000409-11-078	SPRING, THROTTLE VALVE RETURNING	1
E11-6	11	DA04-WC0111-000409-11-079	BOLT, GOVERNOR SUPPORT	1
E11-7	11	DA04-WC0111-000409-11-080	HEXAGON NUT WITH FLANGE	1
E11-8	11	DA04-WC0111-000409-11-081	GOVERNOR BRACKET SUBASSEMBLY	1




PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
F01-1	12	DA04-WC0111-000409-12-082	AIR CLEANER	1
F01-2	12	DA04-WC0111-000409-12-083	HEXAGON NUT WITH FLANGE	2



PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
F02-1	13	DA04-WC0111-000409-13-084	MUFFLER ASSY.	1
F02-2	13	DA04-WC0111-000409-13-085	GASKET, EXHAUST OUTLET	1
F02-3	13	DA04-WC0111-000409-13-086	TYPE 1 HEXAGON NUT	2



PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
F03-1	14	DA04-WC0111-000409-14-087	FUEL TANK	1
F03-2	14	DA04-WC0111-000409-14-088	STRAINER, FUEL	1
F03-3	14	DA04-WC0111-000409-14-089	COVER, FUEL TANK	1
F03-4	14	DA04-WC0111-000409-14-090	BOLT	1
F03-5	14	DA04-WC0111-000409-14-091	HEXAGON NUT WITH FLANGE	2
F03-6	14	DA04-WC0111-000409-14-092	OUTLET SUBASSEMBLY, FUEL TANK OIL	1
F03-7	14	DA04-WC0111-000409-14-093	COLLAR	1
F03-8	14	DA04-WC0111-000409-14-094	TUBE, FUEL	1
F03-9	14	DA04-WC0111-000409-14-095	JACKET, RUBBER	1
F03-10	14	DA04-WC0111-000409-14-096	COLLAR	1



PART NO.	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION
1	DA04-WC0111-000409-00-001	MAINFRAME
2	DA04-WC0111-000409-00-002	DRUM ROLLER
3	DA04-WC0111-000409-00-003	BLADE
4	DA04-WC0111-000409-00-004	ANVIL
5	DA04-WC0111-000409-00-005	INFEED HOPPER TOP PART
6	DA04-WC0111-000409-00-006	INFEED HOPPER BOTTOM PART
7	DA04-WC0111-000409-00-007	EXTENSION TABLE
8	DA04-WC0111-000409-00-008	ANVIL ADJUSTER
9	DA04-WC0111-000409-00-009	BEARING COVER
10	DA04-WC0111-000409-00-010	ENGINE
11	DA04-WC0111-000409-00-011	BASE MODULE
12	DA04-WC0111-000409-00-012	ENGINE FITTING PLATE
13	DA04-WC0111-000409-00-013	FOOT RUBBER
14	DA04-WC0111-000409-00-014	WHEEL AXLE
15	DA04-WC0111-000409-00-015	WHEEL
16	DA04-WC0111-000409-00-016	DISCHARGE HOPPER
17	DA04-WC0111-000409-00-017	DEFLECTOR
18	DA04-WC0111-000409-00-018	RESIST RUBBER
19	DA04-WC0111-000409-00-019	FITTING BAR
20	DA04-WC0111-000409-00-020	ADJUST SCREW
21	DA04-WC0111-000409-00-021	M12*40 THIN HEAD SCREW
22	DA04-WC0111-000409-00-022	STOP BUTTON
23	DA04-WC0111-000409-00-023	BUTTON FRAME
24	DA04-WC0111-000409-00-024	BEARING BASE FC206
25	DA04-WC0111-000409-00-025	WASHER PLATE
26	DA04-WC0111-000409-00-026	DRUM COVER
27	DA04-WC0111-000409-00-027	LONG CONNECT SHEET
28	DA04-WC0111-000409-00-028	SHORT CONNECT SHEET