




**DAEWOO**  
POWER PRODUCTS


**DAFDWC230**  
WOOD CHIPPER



**EXPLODED VIEW / DESPIECE / VUE ÉCLATÉE**


[www.daewoopowerproducts.com](http://www.daewoopowerproducts.com)

Manufactured under license of Daewoo International Corporation, Korea  
Fabricado bajo licencia de Daewoo International Corporation, Corea




PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
E01-1	1	DA04-WC0111-000409-01-001	CRANKCASE SUBASSEMBLY.	1
E01-2	1	DA04-WC0111-000409-01-002	SENSOR, ENGINE OIL	1
E01-3	1	DA04-WC0111-000409-01-003	GEAR ASSY, GOVERNOR	1
E01-7	1	DA04-WC0111-000409-01-004	ARM, GOVERNOR	1
E01-8	1	DA04-WC0111-000409-01-005	BOLT, DRAIN PLUG	2
E01-9	1	DA04-WC0111-000409-01-006	FLAT WASHER	2
E01-12	1	DA04-WC0111-000409-01-007	DEEP GROOVE BALL BEARING	1
E02-13	1	DA04-WC0111-000409-01-008	SEAL, OIL	1
E02-15	1	DA04-WC0111-000409-01-009	HEXAGON NUT WITH FLANGE	1
E02-16	1	DA04-WC0111-000409-01-010	FLAT WASHER	1
E02-17	1	DA04-WC0111-000409-01-011	COTTER PIN	1
E02-18	1	DA04-WC0111-000409-01-012	BOLT	2


**COVER SUBASSEMBLY, CRANKCASE**




PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
E02-1	2	DA04-WC0111-000409-02-013	COVER, CRANKCASE	1
E02-2	2	DA04-WC0111-000409-02-014	DEEP GROOVE BALL BEARING	1
E02-3	2	DA04-WC0111-000409-02-015	SEAL, OIL	1
E02-4	2	DA04-WC0111-000409-02-016	GASKET, CRANKCASE	1
E02-5	2	DA04-WC0111-000409-02-017	POSITION PIN	2
E02-6	2	DA04-WC0111-000409-02-018	DIPSTICK SUBASSEMBLY, OIL	1
E02-8	2	DA04-WC0111-000409-02-019	PLUG SUBASSEMBLY, ENGINE OIL	1
E02-9	2	DA04-WC0111-000409-02-020	BOLT	6




PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
E03-1	3	DA04-WC0111-000409-03-021	GASKET, CYLINDER HEAD	1
E03-2	3	DA04-WC0111-000409-03-022	COVER SUBASSEMBLY, CYLINDER HEAD	1
E03-3	3	DA04-WC0111-000409-03-023	CYLINDER HEAD COVER GASKET	1
E03-4	3	DA04-WC0111-000409-03-024	TUBE, BREATHER	1
E03-5	3	DA04-WC0111-000409-03-025	BOLT	4
E03-6	3	DA04-WC0111-000409-03-026	STUD BOLT	2
E03-8	3	DA04-WC0111-000409-03-027	STUD BOLT	2
E03-9	3	DA04-WC0111-000409-03-028	POSITION PIN	2
E03-10	3	DA04-WC0111-000409-03-029	CYLINDER HEAD BOLT	4
E03-11	3	DA04-WC0111-000409-03-030	PLUG, SPARK	1
E03-12	3	DA04-WC0111-000409-03-031	HEAD SUBASSEMBLY, CYLINDER	1




PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
E04-1	4	DA04-WC0111-000409-04-032	CRANKSHAFT ASSY.	1




PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
E05-1	5	DA04-WC0111-000409-05-033	RING ASSY, PISTON	1
E05-2	5	DA04-WC0111-000409-05-034	CLIP, PISTON PIN	2
E05-3	5	DA04-WC0111-000409-05-035	PISTON	1
E05-4	5	DA04-WC0111-000409-05-036	PIN, PISTON	1
E05-5	5	DA04-WC0111-000409-05-037	ROD, CONNECTING	1

**TRAIN, VALVE / CAMSHAFT SUBASSEMBLY**



PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
E06-1	6	DA04-WC0111-000409-06-038	CAMSHAFT ASSY.	1
E06-3	6	DA04-WC0111-000409-06-039	VALVES SET	1
E06-5	6	DA04-WC0111-000409-06-040	SEAT, VALVE SPRING	2
E06-6	6	DA04-WC0111-000409-06-041	CLAMP, VALVE LOCK	4
E06-7	6	DA04-WC0111-000409-06-042	SPRING, VALVE	2
E06-8	6	DA04-WC0111-000409-06-043	GUIDE, SEAL	1
E06-9	6	DA04-WC0111-000409-06-044	TAPPET, VALVE	2
E06-10	6	DA04-WC0111-000409-06-045	LIFTER, VALVE	2
E06-11	6	DA04-WC0111-000409-06-046	PLATE SUBASSEMBLY, LIFTER STOPPER	1
E06-12	6	DA04-WC0111-000409-06-047	ROCKSHAFT BOLT	2
E06-13	6	DA04-WC0111-000409-06-048	ROCKER, VALVE	2
E06-14	6	DA04-WC0111-000409-06-049	NUT, VALVE ADJUSTING	2
E06-15	6	DA04-WC0111-000409-06-050	NUT, VALVE LOCK	2




PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
E07-1	7	DA04-WC0111-000409-07-051	BOLT	3
E07-2	7	DA04-WC0111-000409-07-052	STARTER ASSY, RECOIL	1



PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
E08-1	8	DA04-WC0111-000409-08-053	SHROUD	1
E08-2	8	DA04-WC0111-000409-08-054	SHROUD, CYLINDER BODY	1
E08-3	8	DA04-WC0111-000409-08-055	SHIELD, LOWER	1
E08-4	8	DA04-WC0111-000409-08-056	PROTECTOR, OIL	1
E08-5	8	DA04-WC0111-000409-08-057	SWITCH SUBASSEMBLY, STOP ENGINE	1
E08-6	8	DA04-WC0111-000409-08-058	BOLT	2
E08-7	8	DA04-WC0111-000409-08-059	BOLT	1
E08-8	8	DA04-WC0111-000409-08-060	COLLAR	1
E08-9	8	DA04-WC0111-000409-08-061	BOLT	1
E08-10	8	DA04-WC0111-000409-08-062	BOLT	4




PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
E09-1	9	DA04-WC0111-000409-09-063	CARBURETOR ASSY.	1
E09-2	9	DA04-WC0111-000409-09-064	AIR CLEANER SEAL GASKET	1
E09-3	9	DA04-WC0111-000409-09-065	CARBURETOR SEAL GASKET	1
E09-4	9	DA04-WC0111-000409-09-066	PLATE, CARBURETOR INSULATOR	1
E09-5	9	DA04-WC0111-000409-09-067	GASKET, CARBURETOR INSULATOR	1




PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
E10-1	10	DA04-WC0111-000409-10-068	NUT, FLYWHEEL	1
E10-2	10	DA04-WC0111-000409-10-069	PULLEY, STARTER	1
E10-3	10	DA04-WC0111-000409-10-070	IMPELLER	1
E10-4	10	DA04-WC0111-000409-10-071	FLYWHEEL SUBASSEMBLY	1
E10-5	10	DA04-WC0111-000409-10-072	COIL, IGNITION	1
E10-6	10	DA04-WC0111-000409-10-073	BOLT	2


**CONTROL ASSY, THROTTLE - CLEANER, AIR**




PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
E11-1	11	DA04-WC0111-000409-11-074	CONTROL ASSY, THROTTLE	1
E11-2	11	DA04-WC0111-000409-11-075	BOLT	2
E11-3	11	DA04-WC0111-000409-11-076	SPRING, GOVERNOR	1
E11-4	11	DA04-WC0111-000409-11-077	ROD, GOVERNEOR	1
E11-5	11	DA04-WC0111-000409-11-078	SPRING, THROTTLE VALVE RETURNING	1
E11-6	11	DA04-WC0111-000409-11-079	BOLT, GOVERNOR SUPPORT	1
E11-7	11	DA04-WC0111-000409-11-080	HEXAGON NUT WITH FLANGE	1
E11-8	11	DA04-WC0111-000409-11-081	GOVERNOR BRACKET SUBASSEMBLY	1




PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
F01-1	12	DA04-WC0111-000409-12-082	AIR CLEANER	1
F01-2	12	DA04-WC0111-000409-12-083	HEXAGON NUT WITH FLANGE	2



PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
F02-1	13	DA04-WC0111-000409-13-084	MUFFLER ASSY.	1
F02-2	13	DA04-WC0111-000409-13-085	GASKET, EXHAUST OUTLET	1
F02-3	13	DA04-WC0111-000409-13-086	TYPE 1 HEXAGON NUT	2



PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
F03-1	14	DA04-WC0111-000409-14-087	FUEL TANK	1
F03-2	14	DA04-WC0111-000409-14-088	STRAINER, FUEL	1
F03-3	14	DA04-WC0111-000409-14-089	COVER, FUEL TANK	1
F03-4	14	DA04-WC0111-000409-14-090	BOLT	1
F03-5	14	DA04-WC0111-000409-14-091	HEXAGON NUT WITH FLANGE	2
F03-6	14	DA04-WC0111-000409-14-092	OUTLET SUBASSEMBLY, FUEL TANK OIL	1
F03-7	14	DA04-WC0111-000409-14-093	COLLAR	1
F03-8	14	DA04-WC0111-000409-14-094	TUBE, FUEL	1
F03-9	14	DA04-WC0111-000409-14-095	JACKET, RUBBER	1
F03-10	14	DA04-WC0111-000409-14-096	COLLAR	1



PART NO.	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION
1	DA04-WC0111-000409-00-001	MAINFRAME
2	DA04-WC0111-000409-00-002	DRUM ROLLER
3	DA04-WC0111-000409-00-003	BLADE
4	DA04-WC0111-000409-00-004	ANVIL
5	DA04-WC0111-000409-00-005	INFEED HOPPER TOP PART
6	DA04-WC0111-000409-00-006	INFEED HOPPER BOTTOM PART
7	DA04-WC0111-000409-00-007	EXTENSION TABLE
8	DA04-WC0111-000409-00-008	ANVIL ADJUSTER
9	DA04-WC0111-000409-00-009	BEARING COVER
10	DA04-WC0111-000409-00-010	ENGINE
11	DA04-WC0111-000409-00-011	BASE MODULE
12	DA04-WC0111-000409-00-012	ENGINE FITTING PLATE
13	DA04-WC0111-000409-00-013	FOOT RUBBER
14	DA04-WC0111-000409-00-014	WHEEL AXLE
15	DA04-WC0111-000409-00-015	WHEEL
16	DA04-WC0111-000409-00-016	DISCHARGE HOPPER
17	DA04-WC0111-000409-00-017	DEFLECTOR
18	DA04-WC0111-000409-00-018	RESIST RUBBER
19	DA04-WC0111-000409-00-019	FITTING BAR
20	DA04-WC0111-000409-00-020	ADJUST SCREW
21	DA04-WC0111-000409-00-021	M12*40 THIN HEAD SCREW
22	DA04-WC0111-000409-00-022	STOP BUTTON
23	DA04-WC0111-000409-00-023	BUTTON FRAME
24	DA04-WC0111-000409-00-024	BEARING BASE FC206
25	DA04-WC0111-000409-00-025	WASHER PLATE
26	DA04-WC0111-000409-00-026	DRUM COVER
27	DA04-WC0111-000409-00-027	LONG CONNECT SHEET
28	DA04-WC0111-000409-00-028	SHORT CONNECT SHEET