




DAEWOO
POWER PRODUCTS


DAFWC600
WOOD CHIPPER



EXPLODED VIEW / DESPIECE / VUE ÉCLATÉE


www.daewoopowerproducts.com

Manufactured under license of Daewoo International Corporation, Korea
Fabricado bajo licencia de Daewoo International Corporation, Corea




PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
E01-1	1	DA04-WC0411-000409-01-001	CRANKCASE SUBASSEMBLY.	1
E01-2	1	DA04-WC0411-000409-01-002	SEAL, OIL	1
E01-3	1	DA04-WC0411-000409-01-003	SENSOR, ENGINE OIL	1
E01-4	1	DA04-WC0411-000409-01-004	PLUG, RUBBER	1
E01-5	1	DA04-WC0411-000409-01-005	PROTECTOR, OIL	1
E01-6	1	DA04-WC0411-000409-01-006	BOLT	1
E01-7	1	DA04-WC0411-000409-01-007	WASHER, FLAT	2
E01-8	1	DA04-WC0411-000409-01-008	BOLT, DRAIN PLUG	2
E01-9	1	DA04-WC0411-000409-01-009	CLIP	1
E01-10	1	DA04-WC0411-000409-01-010	ARM, GOVERNOR	1
E01-11	1	DA04-WC0411-000409-01-011	SEAL, OIL	1
E01-12	1	DA04-WC0411-000409-01-012	PIN	1
E01-13	1	DA04-WC0411-000409-01-013	NUT	1
E01-14	1	DA04-WC0411-000409-01-014	BOLT	2
E01-15	1	DA04-WC0411-000409-01-015	WASHER, FLAT	1
E01-16	1	DA04-WC0411-000409-01-016	BEARING, DEEP GROOVE BALL	1
E02-1	2	DA04-WC0411-000409-02-017	COVER, CRANKCASE	1
E02-2	2	DA04-WC0411-000409-02-018	GASKET, CRANKCASE	1
E02-3	2	DA04-WC0411-000409-02-019	PLUG SUBASSEMBLY, ENGINE OIL	1
E02-4	2	DA04-WC0411-000409-02-020	DIPSTICK SUBASSEMBLY, OIL	1


COVER SUBASSEMBLY, CRANKCASE




PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
E02-5	2	DA04-WC0411-000409-02-021	PIN	2
E02-6	2	DA04-WC0411-000409-02-022	BOLT	7
E02-7	2	DA04-WC0411-000409-02-023	BEARING, DEEP GROOVE BALL	1
E02-8	2	DA04-WC0411-000409-02-024	GEAR ASSY, GOVERNOR	1
E02-9	2	DA04-WC0411-000409-02-025	SEAL, OIL	1
E02-10	2	DA04-WC0411-000409-02-026	BEARING, DEEP GROOVE BALL	1



PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
E03-1	3	DA04-WC0411-000409-03-027	GASKET, CYLINDER HEAD	1
E03-2	3	DA04-WC0411-000409-03-028	COVER SUBASSEMBLY, CYLINDER HEAD	1
E03-3	3	DA04-WC0411-000409-03-029	GASKET, CYLINDER HEAD COVER	1
E03-4	3	DA04-WC0411-000409-03-030	TUBE, BREATHER	1
E03-5	3	DA04-WC0411-000409-03-031	BOLT, CYLINDER HEAD	1
E03-6	3	DA04-WC0411-000409-03-032	Cylinder epicranium bolt seal&gasket unit	1
E03-7	3	DA04-WC0411-000409-03-033	BOLT	2
E03-8	3	DA04-WC0411-000409-03-034	BOLT	2
E03-9	3	DA04-WC0411-000409-03-035	PIN	2
E03-10	3	DA04-WC0411-000409-03-036	BOLT, CYLINDER HEAD	4
E03-11	3	DA04-WC0411-000409-03-037	PLUG, SPARK	1
E03-12	3	DA04-WC0411-000409-03-038	HEAD SUBASSEMBLY, CYLINDER	1




PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
E04-1	4	DA04-WC0411-000409-04-039	CRANKSHAFT ASSY.	1
E04-4	4	DA04-WC0411-000409-04-040	SHAFT ASSY, BALANCING	1




PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
E05-1	5	DA04-WC0411-000409-05-041	RING ASSY, PISTON	1
E05-2	5	DA04-WC0411-000409-05-042	CLIP, PISTON PIN	2
E05-3	5	DA04-WC0411-000409-05-043	PISTON	1
E05-4	5	DA04-WC0411-000409-05-044	PIN, PISTON	1
E05-5	5	DA04-WC0411-000409-05-045	ROD, CONNECTING	1


TRAIN, VALVE / CAMSHAFT SUBASSEMBLY




PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
E06-1	6	DA04-WC0411-000409-06-046	CAMSHAFT ASSY.	1
E06-4	6	DA04-WC0411-000409-06-047	VALVE	1
E06-5	6	DA04-WC0411-000409-06-048	SPRING, VALVE	2
E06-6	6	DA04-WC0411-000409-06-049	RETAINER, EXHAUST VALVE	1
E06-7	6	DA04-WC0411-000409-06-050	ROTATOR, VALVE	1
E06-8	6	DA04-WC0411-000409-06-051	GUIDE, SEAL	1
E06-9	6	DA04-WC0411-000409-06-052	SEAT, VALVE SPRING	1
E06-10	6	DA04-WC0411-000409-06-053	TAPPET, VALVE	2
E06-11	6	DA04-WC0411-000409-06-054	LIFTER SUBASSEMBLY, VALVE	2
E06-12	6	DA04-WC0411-000409-06-055	PLATE SUBASSEMBLY, LIFTER STOPPER	1
E06-13	6	DA04-WC0411-000409-06-056	BOLT, ROCKER SHAFT	2
E06-14	6	DA04-WC0411-000409-06-057	ROCKER, VALVE	2
E06-15	6	DA04-WC0411-000409-06-058	NUT, VALVE ADJUSTING	2
E06-16	6	DA04-WC0411-000409-06-059	NUT, VALVE LOCK	2
E06-17	6	DA04-WC0411-000409-06-060	RETAINER, VALVE SPRING	1




PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
E07-1	7	DA04-WC0411-000409-07-061	STARTER ASSY, RECOIL	1
E07-2	7	DA04-WC0411-000409-07-062	BOLT	3



PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
E08-1	8	DA04-WC0411-000409-08-063	SHROUD	1
E08-2	8	DA04-WC0411-000409-08-064	SHROUD, CYLINDER BODY	1
E08-3	8	DA04-WC0411-000409-08-065	BOLT	1
E08-4	8	DA04-WC0411-000409-08-066	BOLT	5
E08-6	8	DA04-WC0411-000409-08-067	CLIP	1




PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
E09-1	9	DA04-WC0611-000409-09-068	CARBURETOR ASSY.	1
E09-2	9	DA04-WC0611-000409-09-069	GASKET, AIR CLEANER	1
E09-3	9	DA04-WC0611-000409-09-070	GASKET, CARBURETOR	1
E09-4	9	DA04-WC0611-000409-09-071	PLATE, CARBURETOR INSULATOR	1
E09-5	9	DA04-WC0611-000409-09-072	GASKET, INLET	1




PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
E10-1	10	DA04-WC0611-000409-10-073	NUT, FLYWHEEL	1
E10-2	10	DA04-WC0611-000409-10-074	PULLEY, STARTER	1
E10-3	10	DA04-WC0611-000409-10-075	IMPELLER	1
E10-4	10	DA04-WC0611-000409-10-076	FLYWHEEL SUBASSEMBLY	1
E10-5	10	DA04-WC0611-000409-10-077	BOLT	4
E10-6	10	DA04-WC0611-000409-10-078	COIL, IGNITION	1
E10-7	10	DA04-WC0611-000409-10-079	COIL SUBASSEMBLY, CHARGE	1
E10-9	10	DA04-WC0611-000409-10-080	BOLT	1
E10-10	10	DA04-WC0611-000409-10-081	CLAMP, CHARGE COIL	1

CONTROL ASSY, THROTTLE - START-UP ELECTRIC MACHINE COMPONENTS




PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
E11-1	11	DA04-WC0611-000409-11-082	CONTROL ASSY, THROTTLE	1
E11-2	11	DA04-WC0611-000409-11-083	SPRING, THROTTLE VALVE RETURNING	1
E11-3	11	DA04-WC0611-000409-11-084	ROD, GOVERNEOR	1
E11-4	11	DA04-WC0611-000409-11-085	SPRING, GOVERNOR	1
E11-5	11	DA04-WC0611-000409-11-086	SUPPORT SUBASSEMBLY, GOVERNOR	1
E11-6	11	DA04-WC0611-000409-11-087	BOLT	2
E11-7	11	DA04-WC0611-000409-11-088	NUT	1
E11-8	11	DA04-WC0611-000409-11-089	BOLT, GOVERNOR SUPPORT	1




PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
E12-1	12	DA04-WC0611-000409-12-090	MOTOR, STARTING	1
E12-2	12	DA04-WC0611-000409-12-091	BOLT	2
E12-3	12	DA04-WC0611-000409-12-092	BOX, MOTOR CONTROL	1
E12-4	12	DA04-WC0611-000409-12-093	BOLT	2


CLEANER, AIR - MUFFLER ASSY




PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
F01-1	13	DA04-WC0411-000409-13-094	NUT	2
F01-2	13	DA04-WC0411-000409-13-095	ELEMENT, AIR CLEANER	1
F01-3	13	DA04-WC0411-000409-13-096	BOLT	1
F01-4	13	DA04-WC0411-000409-13-097	CLEANER, AIR	1



PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
F02-4	14	DA04-WC0411-000409-14-098	GASKET, MUFFLER	1
F02-5	14	DA04-WC0411-000409-14-099	PIPE, EXHAUST	1
F02-6	14	DA04-WC0411-000409-14-100	GASKET, EXHAUST OUTLET	1
F02-8	14	DA04-WC0411-000409-14-101	NUT	5
F02-9	14	DA04-WC0411-000409-14-102	MUFFLER ASSY.	1



PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
F03-1	15	DA04-WC0411-000409-15-103	TANK, FUEL	1
F03-2	15	DA04-WC0411-000409-15-104	STRAINER, FUEL	1
F03-3	15	DA04-WC0411-000409-15-105	COVER, FUEL TANK	1
F03-4	15	DA04-WC0411-000409-15-106	OUTLET SUBASSEMBLY, FUEL TANK OIL	1
F03-5	15	DA04-WC0411-000409-15-107	COLLAR	2
F03-6	15	DA04-WC0411-000409-15-108	TUBE, FUEL	1
F03-7	15	DA04-WC0411-000409-15-109	NUT	2
F03-8	15	DA04-WC0411-000409-15-110	BOLT	2



PART NO.	PAGE	DAEWOO PART REFERENCE CODE	SPARE PART DESCRIPTION	QTY
1	16	DA04-WC0411-000409-16-111	MAIN BODY	-
2	16	DA04-WC0411-000409-16-112	WHEEL	-
3	16	DA04-WC0411-000409-16-113	WHEEL COVER	-
4	16	DA04-WC0411-000409-16-114	BLADE SYSTEM ASSY.	-
5	16	DA04-WC0411-000409-16-115	FILTER NET	-
6	16	DA04-WC0411-000409-16-116	DOOR PLATE	-
7	16	DA04-WC0411-000409-16-117	ANVIL	-
8	16	DA04-WC0411-000409-16-118	ENGINE PLATE	-
9	16	DA04-WC0411-000409-16-119	REAR PLATE	-
10	16	DA04-WC0411-000409-16-120	F208 BEARING BASE	-
11	16	DA04-WC0411-000409-16-121	ENGINE PULLEY	-
12	16	DA04-WC0411-000409-16-122	DISK PULLEY	-
13	16	DA04-WC0411-000409-16-123	BELT	-
14	16	DA04-WC0411-000409-16-124	BELT COVER	-
15	16	DA04-WC0411-000409-16-125	TOW BAR	-
16	16	DA04-WC0411-000409-16-126	TOW HITCH	-
17	16	DA04-WC0411-000409-16-127	FOOT	-
18	16	DA04-WC0411-000409-16-128	RUBBER PAD	-
19	16	DA04-WC0411-000409-16-129	TOOL BOX(OPT.)	-
20	16	DA04-WC0411-000409-16-130	TOOL BOX COVER(OPT.)	-
21	16	DA04-WC0411-000409-16-131	DISCHARGE	-
22	16	DA04-WC0411-000409-16-132	WHEEL AXIS	-
23	16	DA04-WC0411-000409-16-133	BATTERY BOX(OPT.)	-
24	16	DA04-WC0411-000409-16-134	BATTERY(OPT.)	-
25	16	DA04-WC0411-000409-16-135	CLOVER BOLT	-
26	16	DA04-WC0411-000409-16-136	SWITCH	-
27	16	DA04-WC0411-000409-16-137	SWITCH PLATE	-
28	16	DA04-WC0411-000409-16-138	SPRING	-
29	16	DA04-WC0411-000409-16-139	CHAIN	-
30	16	DA04-WC0411-000409-16-140	PIN	-
31	16	DA04-WC0411-000409-16-141	ENGINE	-
32	16	DA04-WC0411-000409-16-142	CONNECT FRAME	-
33	16	DA04-WC0411-000409-16-143	BELT COVER BOTTOM PART	-
34	16	DA04-WC0411-000409-16-144	TENSION ASSY.	-
35	16	DA04-WC0411-000409-16-145	TENSION BASE	-
36	16	DA04-WC0411-000409-16-146	DEFLECTOR	-
37	16	DA04-WC0411-000409-16-147	INFEED TOP PART	-
38	16	DA04-WC0411-000409-16-148	INFEED BOTTOM PART	-
39	16	DA04-WC0411-000409-16-149	EMERGENCY BAR	-
40	16	DA04-WC0411-000409-16-150	ARM	-
41	16	DA04-WC0411-000409-16-151	BUCKLE	-
42	16	DA04-WC0411-000409-16-152	RESTRICT PLATE	-
43	16	DA04-WC0411-000409-16-153	OUTER RING	-
44	16	DA04-WC0411-000409-16-154	LEFT RING	-
45	16	DA04-WC0411-000409-16-155	RIGHT RING	-
46	16	DA04-WC0411-000409-16-156	SWITCH COVER	-
47	16	DA04-WC0411-000409-16-157	SPRING FRAME	-
48	16	DA04-WC0411-000409-16-158	RUBBER PLATE	-
49	16	DA04-WC0411-000409-16-159	RUBBER FITTING BAR	-
50	16	DA04-WC0411-000409-16-160	M10*30 BOLT	-
51	16	DA04-WC0411-000409-16-161	PIN 4*32	-
52	16	DA04-WC0411-000409-16-162	SPRING WASHER 10	-
53	16	DA04-WC0411-000409-16-163	SPRING WASHER 12	-
54	16	DA04-WC0411-000409-16-164	SPRING WASHER 16	-
55	16	DA04-WC0411-000409-16-165	SPRING WASHER 8	-
56	16	DA04-WC0411-000409-16-166	FLAT WASHER 12	-
57	16	DA04-WC0411-000409-16-167	FLAT WASHER 16	-
58	16	DA04-WC0411-000409-16-168	FLAT WASHER 10	-
59	16	DA04-WC0411-000409-16-169	FLAT WASHER 8	-
60	16	DA04-WC0411-000409-16-170	FLAT WASHER 10	-
61	16	DA04-WC0411-000409-16-171	FLAT WASHER 8	-
62	16	DA04-WC0411-000409-16-172	SPRING WASHER 40	-
63	16	DA04-WC0411-000409-16-173	KEYWAY 6*50	-
64	16	DA04-WC0411-000409-16-174	KEYWAY 10*36	-
65	16	DA04-WC0411-000409-16-175	HEX BOLT M12*25	-
66	16	DA04-WC0411-000409-16-176	HEX BOLT M12*55	-
67	16	DA04-WC0411-000409-16-177	HEX BOLT M12*30	-
68	16	DA04-WC0411-000409-16-178	HEX BOLT M16*70	-
69	16	DA04-WC0411-000409-16-179	HEX BOLT M10*55	-
70	16	DA04-WC0411-000409-16-180	HEX BOLT M12*80	-
71	16	DA04-WC0411-000409-16-181	HEX BOLT M12*100	-
72	16	DA04-WC0411-000409-16-182	HEX BOLT M10*70	-
73	16	DA04-WC0411-000409-16-183	HEX BOLT M10*80	-
74	16	DA04-WC0411-000409-16-184	HEX BOLT M8*25	-
75	16	DA04-WC0411-000409-16-185	HEX BOLT M8*20	-
76	16	DA04-WC0411-000409-16-186	HEX FLANGE BOLT M8*16	-
77	16	DA04-WC0411-000409-16-187	HEX NUT M12	-
78	16	DA04-WC0411-000409-16-188	HEX NUT M10	-
79	16	DA04-WC0411-000409-16-189	HEX FLANGE NUT M8	-
80	16	DA04-WC0411-000409-16-190	HEX LOCK NUT M10	-
81	16	DA04-WC0411-000409-16-191	HEX LOCK NUT M12	-
82	16	DA04-WC0411-000409-16-192	HEX LOCK NUT M16	-
83	16	DA04-WC0411-000409-16-193	HEX LOCK NUT M8	-
84	16	DA04-WC0411-000409-16-194	HEX SLOT NUT M24	-